



67XXU

USB/Serial Scale Series



Service Manual

SOFTWARE VERSION 1.20

Brecknell is part of Avery Weigh-Tronix. Avery Weigh-Tronix is a trademark of the Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc (“Illinois Tool Works”). Copyright © 2014 Illinois Tool Works. All rights reserved.

No part of this publication may be reproduced by making a facsimile copy, by the making of a copy in three dimensions of a two-dimensional work and the making of a copy in two dimensions of a three-dimensional work, stored in any medium by electronic means, or transmitted in any form or by any means, including electronic, mechanical, broadcasting, recording or otherwise without the prior written consent of the copyright owner, under license, or as permitted by law.

This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.

Table of Contents

| | |
|---|----|
| Chapter 1 General Information and Warnings | 3 |
| About this Manual | 3 |
| Text Conventions | 3 |
| Special Messages | 3 |
| Warnings | 4 |
| Routine Maintenance | 4 |
| Sharp Objects | 4 |
| Cleaning the Indicator | 4 |
| CE Certification | 5 |
| Chapter 2 Installation | 6 |
| Connections | 7 |
| Display | 7 |
| Power Supply | 7 |
| USB Port (Com 1) | 7 |
| RS-232 Serial Port (Com 2) | 7 |
| Remote Display and Mounting | 8 |
| Mainboard | 9 |
| Definition of Connectors and Jumpers | 9 |
| Chapter 3 Specifications | 11 |
| Available Models | 11 |
| Outline Dimensions | 11 |
| Mounting | 12 |
| Power Supply | 12 |
| Display | 12 |
| Keypad | 12 |
| Environment | 12 |
| Load Cell Excitation | 12 |
| Approvals | 12 |
| Communication | 13 |
| Analog Circuitry | 13 |
| Capacity and Division | 13 |
| Accuracy | 13 |
| Calibration Method | 13 |
| Other Main Functions | 14 |
| Chapter 4 Configuration | 15 |
| Front Panel | 15 |
| Keys | 16 |
| Navigating the Weigh Mode | 17 |
| Enter the Weigh Mode | 17 |
| Enter or Exit the HOLD Mode | 17 |
| Zero | 17 |
| Tare | 17 |
| Preset Tare Weight | 17 |
| Clear Tare Weight | 17 |
| Output Data (print to a computer or printer) | 18 |
| Display Gross or Net Weight | 18 |
| Change Weight Unit | 18 |
| Check Weight (compare feature) | 20 |
| Navigating the Count Mode | 20 |
| Enter Count Mode | 20 |
| Obtain Piece Weight | 21 |
| Hold Function | 22 |

| | |
|--|-----------|
| Activate the Hold Function | 22 |
| Access the Hold Mode | 22 |
| Hold Methods | 22 |
| Display Software and Hardware Version | 24 |
| Display Test | 24 |
| Keyboard and Buzzer Test | 24 |
| Serial Port 1/2 (COM1/2) Receiving Test | 25 |
| Serial Port 1/2 (COM1/2) Transmitting Test | 25 |
| Chapter 5 Setup Mode | 26 |
| Entering the Setup Menu | 26 |
| Navigating the Setup Menu | 26 |
| Setup Menu Parameters | 27 |
| CONFIG Menu | 27 |
| USER Menu | 32 |
| CAL Menu | 42 |
| MISC Menu | 44 |
| TEST Menu | 44 |
| Exit the Setup Menu | 45 |
| Chapter 6 Calibration | 46 |
| Enter the Calibration Mode | 46 |
| Zero Point | 46 |
| Linearity | 47 |
| Geographical Adjustment | 48 |
| Gravity Value | 50 |
| Input or View Calibration | 50 |
| Weight Fine-tune | 51 |
| Display ADC Output Code | 51 |
| Chapter 7 Serial Communication | 52 |
| Communication Settings | 52 |
| Com Port 1 | 53 |
| Com Port 2 | 53 |
| Protocol | 53 |
| Transaction String | 53 |
| Commands and Response | 54 |
| Parameter NCI-SCP01 | 54 |
| Parameter ECR-SCP02 | 57 |
| Parameter 8213-SCP03 | 60 |
| Parameter Multi | 63 |
| Parameter EH-SCP (PS-60) | 65 |
| Parameter IBM | 66 |
| Chapter 8 Legal for Trade | 69 |
| Physical Seal | 69 |
| Audit Trail Parameters | 70 |
| View Configuration Counter | 70 |
| View Calibration Counter | 70 |
| Chapter 9 Troubleshooting | 71 |
| Display Characters | 71 |
| Display Symbols | 72 |
| Error Messages and Troubleshooting | 73 |

1 General Information and Warnings

1.1 About this Manual

This manual is divided into chapters by the chapter number and the large text at the top of a page. Subsections are labeled as shown by the 1 and 1.1 headings shown above. -The names of the chapter and the next subsection level appear at the top of alternating pages of the manual to remind you of where you are in the manual. The manual name and page numbers appear at the bottom of the pages.

1.1.1 Text Conventions

The keys used to interface with the 67XXU are located on the front panel of the indicator. The keystrokes are shown in **BOLD** incased between brackets. (e.g. **[ZERO]**)

Displayed messages appear in seven segment display type and reflect the case of the displayed message. (e.g. `LOPFU`)

1.1.2 Special Messages

Examples of special messages you will see in this manual are defined below. The signal words have specific meanings to alert you to additional information or the relative level of hazard.



CAUTION!

This is a Caution symbol.

Cautions give information about procedures that, if not observed, could result in damage to equipment or corruption to and loss of data.



ELECTRICAL WARNING!

THIS IS AN ELECTRICAL WARNING SYMBOL.

ELECTRICAL WARNINGS MEAN THAT FAILURE TO FOLLOW SPECIFIC PRACTICES OR PROCEDURES MAY RESULT IN ELECTROCUTION, ARC BURNS, EXPLOSIONS OR OTHER HAZARDS THAT MAY CAUSE INJURY OR DEATH.



NOTE: *This is a Note symbol. Notes give additional and important information, hints and tips that help you to use your product.*

1.2 Warnings

- Avoid lengthy exposure to extreme heat or cold. Your scale works best when operated at normal room temperature. Always allow the scale to acclimate to a normal room temperature before use.
- Allow sufficient warm up time. Turn the scale on and wait for a few minutes if possible. This will give the internal components a chance to stabilize before weighing.
- These electronic scales are precision instruments. Do not operate near an in-use cell phone, radio, computer or other electronic device. These devices emit RF and can cause unstable scale readings. If your scale ever performs poorly, try moving the scale to a different room or location.
- Avoid using in heavy vibration and airflow conditions.
- Read the weight reading in short time after loading. The output signature of load cell and electronic circuit may be little influenced after weighing for a long time.

1.3 Routine Maintenance



IMPORTANT: *This equipment must be routinely checked for proper operation and calibration. Application and usage will determine the frequency of calibration required for safe operation.*

Always turn off the machine and isolate from the power supply before starting any routine maintenance to avoid the possibility of electric shock.

1.4 Sharp Objects

Do not use sharp objects such as screwdrivers or long fingernails to operate the keys.

1.5 Cleaning the Indicator

Table 1.1 Cleaning DOs and DON'Ts

| DO | DO NOT |
|--|---|
| Wipe down the outside of standard products with a clean cloth, moistened with water and a small amount of mild detergent | Attempt to clean the inside of the indicator |
| | Use harsh abrasives, solvents, scouring cleaners or alkaline cleaning solutions |
| Spray the cloth when using a proprietary cleaning fluid | Spray any liquid directly on to the display window |



1.6 CE Certification

Pending

2 Installation



DANGER: RISK OF ELECTRICAL SHOCK. BE SURE TO UPLUG THE INDICATOR BEFORE REMOVING THE COVER OR OPENING THE UNIT. REFER TO QUALIFIED SERVICE PERSONNEL FOR SERVICE.

1. Unpack the scale and all components from the shipping box.
2. Remove the shipping screw from the under side of the scale base. Refer to [Figure 2.1](#).




Figure 2.1 Shipping Screw Location

3. Connect all necessary cables to the proper connectors. Refer to this section for connection details.
4. Level the scale base using the four leveling feet. View the level bubble located under the platform top.

2.1 Connections

There are connectors located on the side of the scale for the power supply, USB port, RS-232 serial port and display which is used for mounting the display remotely on a wall or a desk.




Figure 2.2 View of Scale Connectors

2.1.1 Display

The indicator display can be removed from the scale and mounted on a wall or desk. Refer to section [2.2](#) for details on mounting.

2.1.2 Power Supply

The 67XXU comes with an external AC to DC power adapter. Simply plug the AC adapter into the DC6V power jack on the scale and then plug into a standard wall outlet.



IMPORTANT: Make sure that the AC voltage and polarity appearing at the wall outlet matches the input voltage as well as the polarity marked on the AC adapter.

2.1.3 USB Port (Com 1)

The USB connector is used as a virtual RS-232 port and USB power supply.

2.1.4 RS-232 Serial Port (Com 2)

The 67XXU comes standard with one full Bi-directional RS-232 serial port designed for connection to either a PC or a serial printer.

- Pin 2 = transmit
- Pin 3 = receive

The RS-232 port connector is a 9-pin female..




Figure 2.3 RS-232 Connector (Com 2)

2.2 Remote Display and Mounting

The indicator is connected to the front of the 67XXU. It can be removed however to accommodate mounting on a wall or desk. Plug the display cable into the *DISPLAY* connector.




Figure 2.4 Indicator Desk Mount




Figure 2.5 Indicator Wall Mount

2.3 Mainboard

Figure 2.6 shows the main board connectors for the loadcell, RS-232 port, USB port, power supply and battery.




Figure 2.6 67XXU Main Circuit Board

2.3.1 Definition of Connectors and Jumpers

Table 2.1 Loadcell Connector

| Pin | Description | In/Out/Power | Electrical Level |
|-----|--------------|--------------|--------------------|
| 1 | + excitation | power output | 5±0.3 VDC (≤0.12A) |
| 2 | + sense | power input | 5±0.3 VDC |
| 3 | - excitation | power ground | 0 VDC |
| 4 | - sense | power input | ≤0.5 VDC |
| 5 | + signal | signal input | 2.5±0.3 VDC |
| 6 | - signal | signal input | 2.5±0.3 VDC |
| 7 | shield | - | - |

Table 2.2 Adapter Power Input Connector (ADP)

| Pin # | Definition | In/Out/Power | Electrical Level |
|-------|-------------------------------|--------------|-------------------------|
| 1 | Adapter input voltage - (GND) | Power ground | 0VDC |
| 2 | Adapter input voltage + | Power input | 6.5 VDC (6-9VDC, ≥0.5A) |

Table 2.3 USB Connector (USB) Com 1

| Pin | Description | In/Out/Power | Electrical Level |
|-----|-------------|--------------|------------------|
| 1 | GND of VDD | power ground | 0 VDC |
| 2 | USB D+ | | 0-5 VDC |
| 3 | USB D- | | 0-5 VDC |
| 4 | USB power | power input | 5±0.25 VDC |

Table 2.4 RS-232 Port Connector (SIO) Com 2

| Pin | Description | In/Out/Power | Electrical Level |
|-----|--------------------------|--------------|------------------|
| 2 | RS-232 transmit on UART0 | Output | -12 to +12 VDC |
| 3 | RS-232 receive on UART0 | Input | -12 to +12 VDC |
| 5 | GND | Power ground | 0 VDC |

Table 2.5 CAL Jumper Set

| Connected Pins | Function |
|----------------|----------------------|
| Push | calibration enabled |
| No push | calibration disabled |

3 Specifications

3.1 Available Models

| | |
|-------|-----------------------|
| 6702U | 6"x10" (15 or 30 lb) |
| 6710U | 10"x10" (15 or 30 lb) |
| 6720U | 12"x14" (15 or 30 lb) |

3.2 Outline Dimensions




Figure 3.1 67XXU Dimension Drawing




Figure 3.2 67XXU Dimension Drawing with Indicator on a Column

3.3 Mounting

- Bracket
- Remote (optional cable required)
- Column (option kit required)

3.4 Power Supply

- AC Adapter: 7-9VDC, ≥500mA, center positive
- USB power supply if USB interface is installed
- Work current: ≤15mA (with backlight off, and no load cells)
 - ≤30mA (with backlight on, and no load cells)
 - ≤50mA (with backlight on and one 350 load cell)

3.5 Display

- 5 1/2-digit, 7-segment, 0.58" (15mm) LCDs

3.5.1 Keypad

- 4 push buttons

3.5.2 Environment

| | |
|---------------------|-----------------------------------|
| Working temperature | -10°C to 40°C |
| Storage temperature | -20°C to 70°C |
| Humidity | 10 to 90% RH without condensation |

3.5.3 Load Cell Excitation

| | |
|--------------|------|
| Voltage | 5VDC |
| Max. Current | 20mA |

3.6 Approvals

| | |
|--------------------|----------|
| NTEP | 13-074 |
| Measurement Canada | AM-5912C |

3.7 Communication

| | |
|----------------------|---|
| Serial port1 | Full-duplex RS-232 |
| Optional Serial Port | USB (Virtual RS-232) |
| Baud Rate | Selectable: 1200-2400-4800-9600-19200-38400 bps |
| Data Output Format | 8N1, 7O1, 7E1 |
| Protocol | programmable |

3.8 Analog Circuitry

- 24-bit A/D converter
- Conversion Speed: 10Hz
- Input range: -15mV to +15mV
- Output code: 1mV input will output about 100,000 raw counts
- Hardware low pass filter and 2 programmable digital low pass filters

3.9 Capacity and Division

- Programmable
- Max display range: -199,999 to 199,999
- Division number range for primary unit: 100-20,000
 - Division number range for second unit: 100-25,000 (division number will be limited by REGUL setting)
- Recommended Sensitivity: $>1\mu\text{V}/\text{display division}$

3.10 Accuracy

$\leq 0.01\%$

3.11 Calibration Method

- Software calibration with long-term storage in EEPROM
- Provides smooth curve fit through four points
- Calibration can be done under kg or lb weight unit with 10% -100%FS standard weight.
- Weight fine adjustment ($\pm 10\%$)
- Geographic adjustment

3.12 Other Main Functions

- Programmable zero range
- Programmable pre-set tare weight
- Programmable automatic zero point tracking
- Programmable motion detection window
- Programmable auto-power off time, backlight working mode
- Programmable hold function with peak weight holding and dynamic weighing
- Available check weighing mode
- Available parts counting mode
- Available units of measure: kg, lb, lb:oz, oz, g, PCS
- Data comparison and indicator in weighing mode and parts counting mode
- Programmable serial output content

4 Configuration

To set up the indicator, you must first enter the appropriate menu mode. The front panel keys become directional navigators to move around in the menus. See [Table 4.2](#) for details.

4.1 Front Panel

The front panel incorporates the display and keypad.

The annunciators used are incorporated in the display. The annunciator will be lit when the mode is active.




Figure 4.1 67XXU Keypad and Display





Table 4.1 LCD Display Annunciators and Definitions

| LCD Annunciator | Description |
|-----------------|--|
| ⇒ 0 ⇐ | Better known as the "Center of Zero" annunciator. It is lit when the scale is at the zero point and the gross weight is 0. |
| NET | Indicates net mode and the tare weight is not 0. |
| lb | Indicates the current unit of measure is lb. |
| oz | Indicates the current unit of measure is oz. |
| kg | Indicates the current unit of measure is kg. |
| g | Indicates the current unit of measure is g. |
| Pcs | Indicates counting mode. Unit of measure is pieces. |
| HOLD | Flashes when HOLD key is pressed. Remains permanently on when the Hold function has become activated. |
| AC/CHG | When battery is being used or charged, is fully charged or not installed. |
| OK | Indicates when data compare is enabled and current data (weight, pieces or percent) is between the specified upper and lower limits. |

4.2 Keys

The keyboard consists of four keys, some of which have multiple functions.

Table 4.2 Function of the Keys

| Key | Mode | Condition | Function |
|---|--|---|---|
|  | Weigh or count | Press for less than 3 seconds | Enter or exit HOLD/PRINT mode |
| | Weigh or count | Press [HOLD] + [ON/OFF] for more than 3 seconds | Enter setup mode |
| | Input data mode | Press for more than 3 seconds | Input decimal point |
| | Input data mode | Press for less than 3 seconds | Rotate the flashed position from right to left |
| | Menu selection mode | | Select next item of current menu |
| | Weigh or count | Press [HOLD] + [UNIT] for more than 3 seconds | Select working mode (weigh or count) |
|  | Weigh mode | Press for less than 3 seconds | Change weighing units: kg->lb->oz lb:oz (not available in some conditions) g (not available in some conditions) kg (not be available in some conditions) |
| | Count mode | Press for less than 3 seconds | To enter piece weight mode (by way of sample or input directly) |
| | Weigh or count | Press for more than 3 seconds | To input compare data (for weight or pieces) of high and low limitation |
| | Display voltage mode | Press for more than 3 seconds | To calibrate input voltage value |
| | Display ADC code mode | | Select displaying code from: no-filter, filter1, filter2 |
| | Input data mode | Press to enter data | one will be added to the flashing digit |
| | Menu selection mode | | Select next item of current menu |
|  | Weigh or count | Press for less than 3 seconds | Tare function |
| | Weigh or count | Press for more than 3 seconds | Input pre-set tare weight at selected weight unit |
| | Input data mode or Menu selection mode | Press to enter data | To confirm input data or current item selection. Select next item of current menu or next operation |
| | Display ADC code mode | | Set or clear tare code |
|  | Power off mode | | Power on |
| | Count or weigh | Press for less than 3 seconds | Zero function |
| | Count or weigh | Press for more than 3 seconds | Power off |
| | Input data | | Ignore current operation |
| Menu selection mode | | Return to last sub-menu | |



NOTE: To access the second function of the key, press and hold the key for more than 3 seconds.

4.3 Navigating the Weigh Mode

4.3.1 Enter the Weigh Mode

Press the **[HOLD]** + **[UNIT]** keys for 3 seconds. Use the **[UNIT]** key to choose the desired mode and the **[TARE]** key to confirm selection and exit to the chosen mode.

4.3.2 Enter or Exit the HOLD Mode

Press the **[HOLD]** key for 3 seconds.

4.3.3 Zero

When the weight is stable and within the zero range, press the **[ZERO]** key to set a new zero point. Refer to [Table 4.3](#) for zero limitations.

4.3.4 Tare

When the gross weight is larger than zero and the scale is stable, press the **[TARE]** key. The indicator will show a net weight of zero and the NET annunciator will be illuminated. Refer to [Table 4.3](#) for tare limitations.

4.3.5 Preset Tare Weight

Enter a preset tare weight by pressing the **[TARE]** key for more than 3 seconds. *P_r_e_s_e_t* will be displayed and the NET annunciator flashes. Use the **[UNIT]** and **[TARE]** key to input the desired tare weight and the **[HOLD]** key to move to the next digit. The value entered must be larger than zero and there is no limitation to preset tare weight. After the tare weight is entered the NET annunciator will illuminate. Refer to [Table 4.3](#) for tare limitations.

Note: This indicator can only save one tare weight. The new tare weight will automatically replace the old one.

4.3.6 Clear Tare Weight

Remove any weight on platform and wait until the scale is stable. Press the **[TARE]** key.

Table 4.3 Zero and Tare Limitations

| Standard | Weight on platform | Data in TARE memory unit | key function | |
|----------|--------------------|--------------------------|------------------------|----------|
| | | | Tare key | Zero key |
| USA | ≤0 | no | No action | Zero |
| | | yes | Clear the tared weight | |
| | >0 | no | Tare | |
| | | yes | | |

| Standard | Weight on platform | Data in TARE memory unit | key function | |
|-------------------------|--------------------|--------------------------|------------------------|---------------------------------|
| | | | Tare key | Zero key |
| Canada | ≤0 | no | No action | Zero |
| | | yes | Clear the tared weight | |
| | >0 | no | Tare | |
| | | yes | No action | |
| Europe | ≤0 | no | No action | Zero |
| | | yes | Clear the tared weight | Zero and clear the tared weight |
| | >0 | no | Tare | Zero |
| | | yes | | Zero and clear the tared weight |
| None (same with Europe) | ≤0 | no | No action | Zero |
| | | yes | Clear the tared weight | Zero and clear the tared weight |
| | >0 | no | Tare | Zero |
| | | yes | | Zero and clear the tared weight |



Zero can only be active when the scale is stable and weight is in SAZSM setting range.

Tare can only be active when the scale is stable.

Clearing the Tare weight or Zeroing the scale will put the indicator into Gross mode.

Adding a Tare weight will put the indicator into Net mode.

4.3.7 Output Data (print to a computer or printer)

When scale is stable press the **[PRINT]** key.

4.3.8 Display Gross or Net Weight

- If the tare weight is not zero, the Net weight will be displayed.
- If the tare weight is zero, Gross weight will be displayed.

4.3.9 Change Weight Unit

Press the **[UNIT]** key to select kg, lb, oz, lb:oz, g. Note: under some conditions oz, lb:oz, g are not available. Please refer the following tables.

Table 4.4 Use kg as Primary Unit

| Calibration Division Value | Display Division Value | | | | |
|----------------------------|------------------------|---------------|-----------|---------------|---------------|
| | kg | g | lb | oz | lb:oz |
| 0.0001kg | 0.0001kg | 0.1g | 0.0002lb | 0.005oz | Not available |
| 0.001kg | 0.001kg | 1g | 0.002lb | 0.05oz | Not available |
| 0.01kg | 0.01kg | 10g | 0.02lb | 0.5oz | 0.5oz |
| 0.1kg | 0.1kg | Not available | 0.2lb | 5oz | Not available |
| 1kg | 1kg | Not available | 2lb | Not available | Not available |
| 0.0002kg | 0.0002kg | 0.2g | 0.0005 lb | 0.01oz | Not available |
| 0.002kg | 0.002kg | 2g | 0.005 lb | 0.1oz | 0.1 oz |
| 0.02kg | 0.02kg | 20g | 0.05 lb | 1oz | 1 oz |
| 0.2kg | 0.2kg | Not available | 0.5 lb | 10oz | Not available |
| 2kg | 2kg | Not available | 5 lb | Not available | Not available |
| 0.0005kg | 0.0005kg | 0.5g | 0.001 lb | 0.02oz | Not available |
| 0.005kg | 0.005kg | 5g | 0.01 lb | 0.2oz | 0.2 oz |
| 0.05kg | 0.05kg | 50g | 0.1 lb | 2oz | 2oz |
| 0.5kg | 0.5kg | Not available | 1 lb | Not available | Not available |
| 5kg | 5kg | Not available | 10 lb | Not available | Not available |

Table 4.5 Use lb as Primary Unit

| Calibration Division Value | Display Division Value | | | | |
|----------------------------|------------------------|---------------|-----------|---------------|---------------|
| | kg | g | lb | oz | lb:oz |
| 0.0001lb | Not available | Not available | 0.0001lb | 0.002oz | Not available |
| 0.001 lb | 0.0005 kg | 0.5g | 0.001 lb | 0.02oz | Not available |
| 0.01 lb | 0.005 kg | 5g | 0.01 lb | 0.2oz | 0.2 oz |
| 0.1 lb | 0.05 kg | 50g | 0.1 lb | 2oz | 2 oz |
| 1 lb | 0.5 kg | Not available | 1 lb | Not available | Not available |
| 0.0002 lb | 0.0001 kg | 0.1g | 0.0002 lb | 0.005oz | Not available |
| 0.002 lb | 0.001 kg | 1g | 0.002 lb | 0.005oz | Not available |
| 0.02 lb | 0.01 kg | 10g | 0.02 lb | 0.5oz | 0.5 oz |
| 0.2 lb | 0.1 kg | Not available | 0.2 lb | 5oz | Not available |
| 2 lb | 1 kg | Not available | 2 lb | Not available | Not available |
| 0.0005 lb | 0.0002 kg | 0.2g | 0.0005 lb | 0.01oz | Not available |
| 0.005 lb | 0.002 kg | 2g | 0.005 lb | 0.1oz | 0.1 oz |
| 0.05 lb | 0.02 kg | 20g | 0.05 lb | 1oz | 1 oz |
| 0.5 lb | 0.2 kg | Not available | 0.5 lb | 10oz | Not available |
| 5 lb | 2 kg | Not available | 5 lb | Not available | Not available |

4.3.10 Check Weight (compare feature)

To make the weight compare function available, set CONFIG-FUNC-COMPAR item to YES (refer to Chapter 5 for details on entering and navigating the setup mode). The high and low limitation of weight should be set correctly according to following steps:

1. In weighing mode or count mode, press the **[UNIT]** key more than 3 seconds to compare the high and low data.
- 1a. If in the weigh mode and the *COMP* parameter is accessed, *UNL.Lb* or *UNL.HG* will be displayed when in the weigh mode. Use the **[UNIT]** key to change the active unit.
- 1b. If in the count mode, go to step 3.
2. Use the **[TARE]** key access the high value. *H, GH* and then *L 0000* will be displayed.
3. Use the **[UNIT]** and **[HOLD]** keys to enter the high value. Note: The **[UNIT]** key changes the flashing digit. The **[HOLD]** key goes to the next digit.
4. Press the **[TARE]** key to confirm the entry.
5. After *L 0^U* is accessed, *L 0000* will be displayed. Use the **[HOLD]** and **[UNIT]** keys to input the low number.
6. Press the **[TARE]** key to confirm.
- 6a. After a reasonable limitation is set and compare is active, one of annunciators OK will be illuminated. The beeper will sound according to its setting in USER-BEEP.
7. Press the **[ZERO]** key to exit the *Comp* mode.



NOTE: If the High number value is 0 or is equal or less than low number, the comparison will be disabled, and the input data has no limitation.

4.4 Navigating the Count Mode

In this mode, the scale will weigh goods, calculate and display its counts after the piece weight of the goods is obtained. The count function must be enabled in the setup mode. The CONFIG-FUNC-COUNT item should be set to YES in CONFIG menu. Refer to Chapter 5 for details on entering and navigating the setup mode.

4.4.1 Enter Count Mode

1. To enter counting mode press the **[HOLD] + [UNIT]** keys for more than 3 seconds. *UE, GH* will be displayed.
2. Use the **[UNIT]** key to select *[0]UNL*.
3. Press **[TARE]** to confirm the parts counting mode. The PCS annunciator will be illuminated.
- 3a. In counting mode, the function of **[ZERO]**, **[TARE]**, **[PRINT]**, **[ON/OFF]** and **[HOLD]** keys are available.

4.4.2 Obtain Piece Weight

There are two ways to obtain the piece weight:

Input Piece Weight Directly

1. Press the **[UNIT]** key.
2. When *100.00* is displayed, press the **[TARE]** key to enter into the piece weight mode.
3. When *UN 1.00g* is shown, use the **[UNIT]** key to select the unit of piece weight.
4. Use the **[TARE]** key to confirm and go to piece weigh entry. The display will show *L0000* (Note: Since the LCD can only show 4 digits, but the software allows 6 digits total, so there will be separate displays: *L0000* and *H00*, *L0000* displays the low position digits and *H00* displays the high position digits).
5. From the *L0000* display, use **[HOLD]** and **[UNIT]** key to input new piece weight.
 - 5a. Press the **[UNIT]** key to increase the numbers.
 - 5b. Press the **[HOLD]** key to change the flashed position.
 - 5c. Press the **[HOLD]** key more than 3 seconds to input decimal point.
 - 5d. If the input piece weight is less than 0.5d, the indicator will display *Pwt.Err* and go back to counting mode.
6. Press the **[TARE]** key to confirm the entry.
7. Press the **[ZERO]** key to exit the piece weight mode and back to counting mode.

Sample a Known Quantity

1. Press the **[UNIT]** key.
2. When *100.00* is shown, use the **[UNIT]** key to select *SPLLO*.
3. Press the **[TARE]** key to weigh samples (which quantity is known) weight, calculate piece weight.
4. When *SPLLO* is shown, remove the sample on scale and press the **[TARE]** key to confirm. Before scale is stable, *SPLLO* will be flashed. After it is stable, it will go to next step.
5. When *SPLHI* is shown, put samples (if quantity is known) onto the scale, Press the **[TARE]** key to confirm reading weight. Before scale is stable, *SPLHI* will be flashed. After it is stable, it will go to next step.
 - 5a. If the calculated piece weight is less than 0.5d, the indicator will display *Pwt.Err* and go back to counting mode. Otherwise, after the reasonable piece weight has been captured, the scale will go back to counting mode. The piece weight will be saved and used again.
6. After *100.00* shown, *L0000* will be displayed.
7. Use the **[UNIT]** and **[HOLD]** keys to input the quantity of samples.

8. Press the **[TARE]** key to confirm the entry.
- 8a. If the calculated piece weight is less than 0.5d, the indicator will display *PULER* and go back to counting mode. Otherwise, after the reasonable piece weight has been captured, the scale will go back to counting mode. The piece weight will be saved and used again.
9. Press the **[ZERO]** key to exit and back to counting mode.

4.5 Hold Function

The HOLD function can be used to freeze a displayed number. In this mode, the scale can capture a dynamic number, hold a stable number, or average a unstable number and then HOLD (freeze) this number temporarily for the user to view or record.

The HOLD function can be used in normal weighing mode and counting mode. After entering HOLD mode, the speed of A/D converter can be increased to 80Hz (if USER-HOLD-AD.H.SP is set to YES) from original 10Hz for some dynamic weighing applications.

It is possible to weigh restless samples such as live animals or moving objects within the HOLD function. The indicator provides special mode settings to accommodate weight movements.

4.5.1 Activate the Hold Function

- The CONFIG-FUNC-HOLD menu item must be set to YES.

Menu items of:

- USER-HOLD-HLD.MD /AVG.TM /HLD.TM/RG /STB.TM
- USER-OTHER-NLD.RG need be set to reasonable values.
- To speed up sampling of weight, set USER-HOLD-AD.H.SP menu item to YES.

4.5.2 Access the Hold Mode

To enter the HOLD mode, press the **[HOLD]** key while in the normal weighing mode or counting mode.

4.5.3 Hold Methods

- Positive Peak Number HOLD mode
- Negative Peak Number HOLD mode
- Toggle HOLD mode
- Average HOLD mode
- Auto HOLD mode

The following are details of these HOLD modes:

Positive Peak HOLD

When USER-HOLD-HLD.MD is set to $P\bar{5}PE\bar{E}$, the hold mode is positive peak hold mode.

When scale first enters this working mode, it will display the largest positive number that is from the time of zero-point set. The scale also will always catch the largest positive number and display it.

To exit HOLD mode, press the **[HOLD]** key again.

Negative Peak HOLD

When USER-HOLD-HLD.MD is set to $\bar{N}GPE\bar{E}$, the hold mode is in negative peak hold mode.

When the scale first enters this mode, it will display the largest negative number from the time of zero-point set. The scale also will always catch the largest negative number and display it.

To exit HOLD mode, press the **[HOLD]** key again.

Toggle HOLD

When USER-HOLD-HLD.MD is set to $\bar{E}OGLE$, the hold mode is toggled between HOLD and MANUAL HOLD function.

After entering this mode, the scale will freeze and display a number if scale is stable. Only the weight that is over USER-OTHER-NLD.RG (zero 'dead' band) can be held.

To exit HOLD mode, press the **[HOLD]** key again. If the time of the scale being unstable is more than USER-HOLD-STB.TM, $\bar{5}t\bar{b}E\bar{r}$ will be shown.

Press the **[TARE]** key to start averaging again or press the **[HOLD]** key to exit.

Average HOLD

Set the USER-HOLD-HLD.MD parameter to $\bar{A}U\bar{E}r\bar{G}$.

After entering this mode the scale will freeze and display number if the scale is stable. If the scale is not stable, but the variation is less than the USER-HOLD-DYN.RG setting, the scale will average data in USER-HOLD-AVG.TM, then freeze and display the number. Only the weight that is over USER-OTHER-NLD.RG can be frozen.

The scale will exit HOLD mode according to the setting of USER-HOLD-HLD.TM. If the time of scale variation is over USER-OTHER-NLD.RG and is more than USER-HOLD-STB.TM, $\bar{5}t\bar{b}E\bar{r}$ will be shown.

Press **[UNIT]** or **[TARE]** to start averaging again, or press the **[HOLD]** key to exit.

Auto HOLD

Set the USER-HOLD-HLD.MD parameter to $\bar{A}U\bar{E}O$. Different items can be weighed one after another without pressing any buttons.

After entering this working mode, scale will freeze and display number if scale is stable. Only the weight that is over USER-OTHER-NLD.RG can be frozen. If the held weight is moved away and a new load is put on the scale, the new load will automatically be held.

The scale will exit HOLD mode according to the setting of USER-HOLD-HLD.TM. If the time of scale variation being over USER-OTHER-NLD.RG is more than USER-HOLD-STB.TM, *StbEr* will be shown. Press the **[TARE]** key to start averaging again or press the **[HOLD]** key to exit.

4.6 Display Software and Hardware Version

Display the current version of software and hardware.

1. Enter the Setup Mode by pressing the **[HOLD] + [ON/OFF]** keys until *COFFG* is displayed.
2. Use the **[UNIT]** key to select the MISC-VER menu.
3. Press **[TARE]** to display the current version.
- 3a. Firmware Version display Format is: Vxx.yy, xx is hardware version, yy is software version.
4. Press the **[ON/OFF]** key to return to last menu item.

4.7 Display Test

1. Press the **[HOLD] + [ON/OFF]** keys until *COFFG* is displayed.
1. Use the **[UNIT]** key to select TEST-DSP.TS menu.
2. Press **[TARE]** to enter the test display mode and all segments will light at first.
- 2a. In this mode, every press of the **[UNIT]** key will light the next segment. Every press of the **[HOLD]** key will light the next digit.
- 2b. Press the **[TARE]** key to automatically light all segments and all digits.
3. Press the **[ON/OFF]** key to return to last menu item.

4.8 Keyboard and Buzzer Test

1. Press the **[HOLD] + [ON/OFF]** keys until *COFFG* is displayed.
2. Use the **[UNIT]** key to select TEST-KEY.TS menu.
3. Press **[TARE]** to enter test keypad mode and *KEY* will be displayed.
4. Press any key. The value of this key will be displayed and the buzzer will beep.
5. Press the **[ON/OFF]** key to return to last menu item.

4.9 Serial Port 1/2 (COM1/2) Receiving Test

Before testing the receiving function of COM1 or COM2, a cable is need to connect a computer to the scale. A terminal program such as Hyper Terminal is also needed for testing.

Note: baud rate is selected by USER-COM1/2-BUD.RT, 8N1 byte format is fixed, Hex data (0x00 - 0xff) are used.

1. Press the **[HOLD] + [ON/OFF]** keys until `[OFF]` is displayed.
2. Use the **[UNIT]** key to select TEST-CM1.RD or TEST-CM2.RD item.
3. Press **[TARE]** to enter test COM1/2 receiving function. `rd 1.- -` or `rd 2.- -` will be displayed.
- 3a. In this mode, received hex data (0x00 - 0xff) will be displayed in `- -` position.
4. Press the **[ON/OFF]** key to return to last menu item.

4.10 Serial Port 1/2 (COM1/2) Transmitting Test

Before testing the receiving function of COM1 or COM2, a cable is need to connect a computer to the scale. A terminal program such as Hyper Terminal is also needed for testing.

Note: baud rate is selected by USER-COM1/2-BUD.RT, 8N1 byte format is fixed, Hex data (0x00 - 0xff) are used.

1. Press the **[HOLD] + [ON/OFF]** keys until `[OFF]` is displayed.
2. Use the **[UNIT]** key to select TEST-CM1.TD or TEST-CM2.TD item.
3. Press **[TARE]** to enter test COM1/2 transmit function. `td 1.- -` or `td 2.- -` will be displayed.
- 3a. In this mode, transmitted hex data (0x00 - 0xff) will be displayed in `- -` position.
4. Press the **[ON/OFF]** key to return to last menu item.

5 Setup Mode


The setup menu consists of five different sub-menus. Within each sub-menu are different menu options.

The config/cal switch must be set in the ON position in order to make changes to specific parameters.

5.1 Entering the Setup Menu





1. Power on the indicator by pressing and holding the **[ON/OFF]** key.
2. Press the **[HOLD] + [ON/OFF]** key for 3 seconds. The indicator shows *CONF* to indicate that you are in Setup Menu mode.

5.2 Navigating the Setup Menu



1. Once *CONF* is displayed, use the **[UNIT]** key to move forward through the menu choices or the **[HOLD]** key to move backward in the setup menu.
2. Use the **[TARE]** key to access the desired menu. (e.g. *USER*)
3. Use the **[UNIT]** key to view the available sub-menus (parameter: e.g. *BEEP*).
4. Use the **[TARE]** key to select the sub-menu.
5. Use the **[UNIT]** key to view the choices within the sub-menu. (e.g. *EEY*)
6. Press the **[TARE]** key to select the desired choice within the sub-menu. Once selected the parameter will be displayed.
7. Press **[ZERO]** to return back up and return to the setup menu.

Table 5.1 Key Navigation

| | |
|---|--|
| [HOLD/PRINT]  | Access the Setup Menu. |
| [UNIT]  | Scroll through available menus. |
| | Choose a sub-menu Make a change within the sub-menu |
| [ZERO/ON/OFF]  | Scroll through available menus. |
| | Choose a sub-menu Make a change within the sub-menu |
| [TARE]  | Choose a sub-menu |

5.3 Setup Menu Parameters

This section provides more detailed descriptions of the selections found in the Setup Menu.

The menu charts show the flow of the parameters and also provide a quick reference to the parameters within the menu.

The menu tables show the submenus, options and default parameter in LCD display format to coincide with the actual display.

5.3.1 CONFIG Menu




Figure 5.1 CONFIG Menu Chart

The figure above is an illustration of the available menus with the CONFIG menu and the choices within those menus. Refer to [Table 5.2](#) for explanations of the menu choices.

Table 5.2 CONFIG Menu Choices and Explanations

| CONFIG | | | | | |
|-----------------|----------|----------------|---------|---|--|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| CF.ON CF.OFF | | | | Seal switch position | The display will show whether the seal switch is in the ON or Off position. This parameter can't be changed within the software. |
| rESEt | | NO | NO | Reset Config menu parameters to default setting | |
| | | YES | | | |
| rEGUL | | NOPE | USA | Select the standard in which the scale will comply: USA, Canada, Europe | *None = not legal for trade. |
| | | USA | | | |
| | | CANdA | | | |
| | | EUrPE | | | |
| Pr i n | | 100 - 20000 | | Primary full scale value | Default full scale value will depend on capacity of scale. *If (REGUL) ≠ none, the max is 10,000 |
| Pr i n d | | 0.0001 | | The division value under primary unit | Default division size will depend on capacity of scale. The division value under second unit is automatically determined by the indicator according to the division value under primary unit. |
| | | 0.0002 | | | |
| | | 0.0005 | | | |
| | | 0.001 | | | |
| | | 0.002 | | | |
| | | 0.005 | | | |
| | | 0.01 | | | |
| | | 0.02 | | | |
| | | 0.05 | | | |
| | | 0.1 | | | |
| | | 0.2 | | | |
| | | 0.5 | | | |
| | | 1 | | | |
| | | 2 | | | |
| 5 | | | | | |

| CONFIG | | | | | |
|-------------|----------|-----------|---------|---|--|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| Pr i n U t | | KG | L b | Primary unit | Select the primary unit from kg or lb. The second unit is lb if kg is selected as the primary unit. *The calibration standard weight must be in the primary unit! |
| | | L b | | | |
| 5 E C d . N | | 100-25000 | | Second scale full scale value | The division number under second unit. The maximum is 1.25*(PRIM.N). *If (REGUL)≠none, the max is 10,000 NOTE: Secondary division has to match the primary division. |
| 10 d 5 P | | No | No | Display weight at 10 times division number under primary unit | *If (REGUL)= none this parameter will not be available. When yes is selected, some menus will not be active. |
| | | YES | | | |
| n o t o N | | 1-255 | 4 | Motion window | 1-255 = ±0.25d *(1-255) *If (REGUL)=none, the max is 12 |
| o v e r . d | | 0- 100 | 0 | Overload display limitation | 0=FS+9d 1-100=101%FS -200%FS. *If (REGUL)=none, the max is 10 |
| U N I T S | KG | YES | YES | UNITS key | YES = enable this unit No = disable this unit In trade applications, lb:oz is not allowed |
| | | No | | | |
| | L b | YES | YES | | |
| | | No | | | |
| | o z | YES | YES | | |
| | | No | | | |
| | L b o z | YES | No | | |
| | | No | | | |
| G | YES | YES | | | |
| | No | | | | |

| CONFIG | | | | | | |
|----------|----------|--------|---------|--|---|--|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment | |
| ZeroPt | iZn | 0-100 | 10 | Initial zero set mechanism | Range of capacity in percent $\pm 0 - 100\%FS$ Also uses SAZSM and AZSM (total) *If (REGUL)=none, the max is 10 | |
| | | uEGHt | CAL.Zr | uEGHt | Inside IZSM | WEIGHT= on power up CAL.ZR= calibration zero point |
| | | | LSt.Zt | | LST.Z.T=store last push button zero and push button tare *If (REGUL) \neqnone, the value is fixed on WEIGHT | |
| | oU.iZn | dP.oUr | dP.oUr | | Outside IZSM | DP.OVR=display initial zero is over. Display will show upper dashes when above capacity |
| | | uEGHt | | WEIGHT= current weight Can zero more weight (approx 90%) before dashes are displayed. Not Legal for Trade | | |
| | | CAL.Zr | | CAL.ZR= calibration zero point will display dashes at 100% | | |
| | | LSt.Zt | | LST.Z.T=Last ZERO and TARE | | |
| | ZArZn | 0-100 | 2 | Zero key range | 0=no limitation 1-100= (initial zero point) $\pm 1\%FS$ - (initial zero point) $\pm 100\%FS$ *If (REGUL) \neqnone, the max is 2 | |
| | | AZn | 0-100 | | 8 | Zero tracking window 0=0d, no tracking 1-100= $\pm(0.2+0.05*(1-100))d/s$ *If (REGUL) \neqnone, the max is 4 |
| | FLtEr | FLtH | 0-255 | 40 | Digital filter1 threshold | 0=no filter1 1-254=filter1 used only when vibration in $\pm 0.25d*(1-254)$ 255= filter1 always used |
| FLtI | | | uEARt | n,dLE | | Digital filter1 intensity Weak = 4 weights to average Midle = 8 weights to average Strong = 16 weights to average |
| | | n,dLE | | | | |
| | | StoNG | | | | |
| FLt2H | | 0-255 | 8 | Digital filter2 threshold | 0=no filter2 1-254=filter2 used only when vibration in $\pm 0.25d*(1-254)$ 255= filter2 always used | |
| | FLt2I | 0-255 | 240 | | Digital filter2 intensity 0-255=weak to strong | |

| CONFIG | | | | | |
|-------------|--------------|------------|------------|--|--|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| <i>FUNC</i> | <i>HoLd</i> | <i>YES</i> | <i>YES</i> | Enable or disable hold function | YES |
| | | <i>NO</i> | | | NO |
| | <i>CoUNt</i> | <i>YES</i> | <i>NO</i> | Enable or disable counting function | YES |
| | | <i>NO</i> | | | NO |
| | <i>CoñPr</i> | <i>YES</i> | <i>NO</i> | Enable or disable data comparison function | YES |
| | | <i>NO</i> | | | NO |
| | <i>GEcAL</i> | <i>YES</i> | <i>NO</i> | Enable or disable the geographical adjustment factor | YES |
| | | <i>NO</i> | | | NO |
| | <i>WEAdj</i> | <i>YES</i> | <i>NO</i> | Enable or disable weight fine-tuning using keypad in weighing mode | YES |
| | | <i>NO</i> | | | NO *If (REGUL) ≠none, this item is NO |

***The setting will be limited by the choice of REGUL**

5.3.2 USER Menu




Figure 5.2 USER Menu Chart

The figure above is an illustration of the available menus with the USER menu and the choices within those menus. Refer to Table 5.3 for explanations of the menu choices.

Table 5.3 User Menu Choices and Explanations

| USER | | | | | |
|----------|----------|--------|---------|--|---------|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| rESEt | | No | No | Reset <i>User</i> menu parameters to default setting | |
| | | Yes | | | |

| USER | | | | | |
|---|----------|---|---------|-------------------------|---|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| COM1 (USB) | Baudr | 1200 | 9600 | Select COM1 baud rate | |
| | | 2400 | | | |
| | | 4800 | | | |
| | | 9600 | | | |
| | | 19200 | | | |
| | | 38400 | | | |
| | BtFnt | 8N1 | 8N1 | Select COM1 byte format | (1) 8N1=8 data bits, No parity check bit, 1 stop bit |
| | | 7O1 | | | (2) 7O1=7 data bits, 1 Odd parity check bit, 1 stop bit |
| | | 7E1 | | | (3) 7E1=7 data bits, 1 Even parity check bit, 1 stop bit |
| | oUEnd | NONE | PrtCd | Select COM1 output mode | (1) NONE=no communication |
| | | CONT | | | (2) CONT=continuously output |
| | | PRINT | | | (3) PRINT=output after [PRINT] key is pressed |
| | | CMD | | | (4) CMD=output after a request command is received |
| | | PRT.CD | | | (5) PRT.CD= output after [PRINT] key is pressed or request command received |
| | | STABL | | | (6) STABL=Sends output automatically after scale is stable. Note: use PRINT or CMD to output data, the scale must be stable |
| ST.NLD | | ** (7) ST.NLD=output after scale has returned to zero range (OTHER>NLD.RG) and is stable. | | | |
| NLD | | ** (8) NLD= Output after scale has returned to zero range (OTHER>NLD.RG) and does not wait for the scale to be stable. | | | |
| PR.NLD | | (9) PR.NLD= Manual push button print once after scale is stable. Scale has to return to zero range (OTHER>NLD.RG) before another push button print command can be executed. | | | |
| **Note: If PRINT, STABL, ST.NLD, LNLD or CMD are used to output data, the scale must be stable. | | | | | |

| USER | | | | | |
|----------|----------|--------|---------|-------------------------------|---|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| | LYOUT | MULTI | MULTI | Set COM1 content and format | (1) MULTI= the following selected item in OUT1 will be output use defined format |
| | | SCP01 | | Emulates NCI protocol | (2) SCP01= only displayed content and current status will be output, it's compatible with NCI-SCP01 |
| | | SCP02 | | Emulates ECR protocol | (3) SCP02= only displayed content and current status will be output. Compatible with ECR-SCP02 |
| | | SCP03 | | Emulates Toledo 8213 protocol | (4) SCP03= only displayed content and current status will be output. Compatible with 8213-SCP03 |
| | | EH-SCP | | Emulates Toledo PS60 | (5) EH-SCP= command response mode (PS-60) |
| | | IBM | | IBM SCP03 protocol | (6) IBM= only displayed content and current status will be output. Compatible with NCI-SCP08 |

| USER | | | | | | |
|---------------|----------|--------|---------|--|---|---|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment | |
| 00E1 (USB) | SC.LID | YES | No | Enable or disable scale ID number | Prompt is "SCALE ID" | |
| | | No | | | | |
| | GROSS | YES | YES | Enable or disable gross weight | Prompt is "GROSS" | |
| | | No | | | | |
| | TARE | YES | YES | Enable or disable tare weight | Prompt is "TARE" | |
| | | No | | | | |
| | NET | YES | YES | Enable or disable net weight | Prompt is "NET" | |
| | | No | | | | |
| | COUNT | YES | No | Enable or disable counts | Prompt is "QUANTITY" | |
| | | No | | | | |
| | PCWT | YES | No | Enable or disable piece weight | Prompt is "PIECE WT" | |
| | | No | | | | |
| | ADCDE | YES | No | Enable or disable ADC code | Prompt is "A/D CODE" | |
| | | No | | | | |
| | B.VOL | YES | No | Enable or disable whether to display the battery voltage | Prompt is "VOLTAGE" | |
| | | No | | | | |
| | STATUS | YES | No | Enable or disable scale status | Prompt is "STATUS" | |
| | | No | | | | |
| | BL,NE | | None | LINE1 | How many blank lines after strings output | NONE=no blank line |
| | | | LINE1 | | | LINE1/2/3/4=there are 1, 2,3 or 4 blank lines after strings, used for paper feed forward 1/2/3/4 lines. |
| LINE2 | | | | | | |
| LINE3 | | | | | | |
| LINE4 | | | | | | |

| USER | | | | | |
|---|------------|---|---------|-------------------------|---|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| COM2 (9 Pin) | BaudRate | 1200 | 9600 | Select COM2 baud rate | |
| | | 2400 | | | |
| | | 4800 | | | |
| | | 9600 | | | |
| | | 19200 | | | |
| | | 38400 | | | |
| | ByteFormat | 8N1 | 7E1 | Select COM2 byte format | (1) 8N1=8 data bits, No parity check bit, 1 stop bit |
| | | 7O1 | | | (2) 7O1=7 data bits, 1 Odd parity check bit, 1 stop bit |
| | | 7E1 | | | (3) 7E1=7 data bits, 1 Even parity check bit, 1 stop bit |
| | OutputMode | NONE | PRT.CD | Select COM2 output mode | (1) NONE=no communication |
| | | CONT | | | (2) CONT=continuously output |
| | | PRINT | | | (3) PRINT=output after PRINT key pressed |
| | | CMD | | | (4) CMD=output after a request command is received |
| | | PRT.CD | | | (5) PRT.CD= output after PRINT key pressed or request command received |
| | | STABL | | | (6) STABL=output after scale is stable; Note: use PRINT or CMD to output data, the scale must be stable |
| ST.NLD | | ** (7) ST.NLD=output after scale has returned to zero range and is stable. (OTHER>NLD.RG) | | | |
| NLD | | ** (8) NLD= Output after scale has returned to zero range and does not wait for the scale to be stable. (OTHER>NLD.RG) | | | |
| PR.NLD | | (9) PR.NLD= Manual push button print once after scale is stable. Scale has to return to zero range (OTHER>NLD.RG) before another push button print command can be executed. | | | |
| **Note: If PRINT, STABL, ST.NLD, LNLd or CMD are used to output data, the scale must be stable. | | | | | |

| USER | | | | | |
|----------|----------|--------|---------|-------------------------------|--|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| | LYOUT | MULTI | MULTI | Set COM2 content and format | (1) MULTI= the following selected item in OUT2 will be output use defined format |
| | | SCP01 | | Emulates NCI protocol | (2) SCP01= only displayed content and current status will be output, it's compatible with NCI-SCP01 |
| | | SCP02 | | Emulates ECR protocol | (3) SCP02= only displayed content and current status will be output, it's compatible with ECR-SCP02 |
| | | SCP03 | | Emulates Toledo 8213 protocol | (4) SCP03= only displayed content and current status will be output, it's compatible with 8213-SCP03 |
| | | EH-SCP | | Emulates Toledo PS60 | (5) EH-SCP= command response mode (PS-60) |
| | | IBM | | IBM SCP03 protocol | (6) IBM= only displayed content and current status will be output. Compatible with NCI-SCP08 |

| USER | | | | | | |
|-----------------|----------|--------|---------|--|---|--|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment | |
| 0002 (9 Pin) | SCALE ID | YES | NO | Enable or disable scale ID number | Prompt is "SCALE ID" | |
| | | NO | | | | |
| | GROSS | YES | YES | Enable or disable gross weight | Prompt is "GROSS" | |
| | | NO | | | | |
| | TARE | YES | YES | Enable or disable tare weight | Prompt is "TARE" | |
| | | NO | | | | |
| | NET | YES | YES | Enable or disable net weight | Prompt is "NET" | |
| | | NO | | | | |
| | COUNT | YES | NO | Enable or disable counts | Prompt is "QUANTITY" | |
| | | NO | | | | |
| | PIECE WT | YES | NO | Enable or disable piece weight | Prompt is "PIECE WT" | |
| | | NO | | | | |
| | A/D CODE | YES | NO | Enable or disable ADC code | Prompt is "A/D CODE" | |
| | | NO | | | | |
| | VOLTAGE | YES | NO | Enable or disable whether to display the battery voltage | Prompt is "VOLTAGE" | |
| | | NO | | | | |
| | STATUS | YES | NO | Enable or disable scale status | Prompt is "STATUS" | |
| | | NO | | | | |
| | BLINE | | NONE | LINE 1 | How many blank lines after strings output | NONE=no blank line |
| | | | LINE 1 | | | LINE 1/2/3/4=there are 1, 2,3 or 4 blank lines after strings, used for paper feed forward 1/2/3/4 lines. |
| LINE 2 | | | | | | |
| LINE 3 | | | | | | |
| LINE 4 | | | | | | |

| USER | | | | | |
|----------------|--------------|--|---------------|--|--|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| <i>bEEP</i> | <i>PEY</i> | <i>YEL</i> | <i>YEL</i> | Enable or disable beep after a key is pressed. | |
| | | <i>Πo</i> | | | |
| | <i>CoñPr</i> | <i>ΠoΠE</i> | <i>,Π.Lñt</i> | | (1) NONE = no beep |
| | | <i>LLoY</i> | | | (2) L.Low = beep when lower than low limitation; |
| | | <i>,Π.Lñt</i> | | | (3) IN.LMT = beep when in range of low and high limitation |
| | | <i>o.H, GH</i> | | | (4) O.HIGH = beep when over high limitation |
| <i>oUT.Lñt</i> | | (5) OUT.LMT = beep when lower than low limitation or higher than high limitation | | | |

| USER | | | | | |
|----------|----------|--------------------------------|-----------------|--|---|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| HoLd | Ad.H.S.P | YES | No | Enable or disable use of the high speed A/D converter after entering the HOLD mode | |
| | | No | | | |
| | HLd.n̄d | NoPE | AUto | Hold mode | (1) NONE= off |
| | | PS.PEK | | | (2) PS.PEK=Positive Peak number Hold mode. Scale will display and refresh the positive peak value from last zero setting. |
| | | NG.PEK | | | (3) NG.PEK=Negative PEAK number Hold mode. It is similar to PS.PEK, but a negative number is used. |
| | | toGLE | | | (4) TOGGLE=Press [HOLD] key to enter HOLD mode. Stores the display value. Will stay on the display for the duration of time set at HLD.TM. |
| | | AVERG | | | (5) AVERG= Average HOLD mode. Time it looks at the weight before updating the display. Set by AVG.TM. Weight or vibration must fall within window of HLD.RG also. |
| | | AUto | | | (6) AUTO=Auto hold mode. It is similar to AVERAG mode, but will allow more weight to be added. |
| | AUG.t̄n̄ | 1-60 | 3 | Average data time for HOLD mode | 1-60 seconds |
| | Stb.t̄n̄ | 311AUG.t̄n̄ - 255 | 311 AUG.t̄n̄ | Wait time for the scale to be stable in HOLD mode | Window which has to be 3 times larger than AVG.TM |
| | HLd.t̄n̄ | 0-65535 | 0 | Data HOLD time | 0=data will be frozen until HOLD key pressed. 1-65535=data frozen time is 1-65535s, after the time elapses, scale will exit HOLD mode. |
| | HLd.r̄G | 0-255 | 5 | Hold range | Window of vibration for Auto to work. 0=any data can be averaged 1-255= only the data which vibration is in 1-255d can be averaged and held. |
| | Hd.PEY | HoLd | HoLd | HOLD/PRINT key | (1) HOLD= only HOLD key |
| | | Pr .n̄t̄ | | | (2) PRINT= only PRINT key |
| HLd.Pr | | (3) HLD.PR= HOLD and PRINT key | | | |

| USER | | | | | |
|----------|---------------|--------|--------------------------------|--|---|
| SubMenu1 | SubMenu2 | Option | Default | Parameter Description | Comment |
| oLHEr | PLd.rG | 1-255 | 10 | No hold range | Load must return to zero in divisions to perform a print when in AUTO. 1-255=the range of weight is 1-255d. When current weight is less than this value, the scale can be regarded as empty, or the load on scale is removed. It must be bigger than (CONFIG.MOTON). |
| | Cn.d.br | None | Cn.1.2 | Command source Turns COM1 / COM2 on/off | (1) NONE=no any command will be executed |
| | | Cn.1 | | | (2) COM.1= command from COM1 will be executed |
| | | Cn.2 | | | (3) COM.2= command from COM2 will be executed |
| | | Cn.1.2 | | | (4) COM.1.2= command from COM1 or COM2 will be executed |
| | LEGACY | 0-2 | 1 | Status bit setting | 0=no change to output string. Can send 3 or 4 status bits |
| | | | | | 1=all data sent of has 2 status bits = bit 6. Character 2 must be set to 0 |
| | | | | | 2=all data sent out has 3 status bits and 7 weight characters. |
| | RoFFt | 0-255 | 0 | Auto off time | 0=not auto power off 1-255=auto power off after 1-255 minutes. In this period, no operation or no weight change |
| | LCd.bl | 0-255 | 30 | LCD backlight set | (1) 0=always off (2) 1=always on (3) 2=press down ZERO+UNIT together more than 3s to turn on or turn off (4) 3-255=auto on when key operation or weight changing. Auto off after 3-255s elapsed. |
| tAREY | YES | No | YES | Tare key enable | Yes= tare key is enabled |
| | No | | | | No= tare key is disabled |
| PHd.rG | 0-8 | 0 | Photo eye TARE sensitivity | (1) 0= remote TARE key disabled (2) 1-8 = sensitivity level 1= close distance - 8= long distance | |
| SC.L.d | 000000-999999 | 123456 | Scale ID number: 000000-999999 | | |

5.3.3 CAL Menu




Figure 5.3 CAL Menu Chart

The figure above is an illustration of the available menus with the CAL menu and the choices within those menus. Refer to [Table 5.4](#) for explanations of the menu choices.

Table 5.4 CAL Menu Choices and Explanations

| CAL | | | | |
|--------------------------------|----------|--------|------------------------|--|
| Submenu1 | Submenu2 | Option | Parameter Description | Comment |
| <i>CAL.ON</i> <i>CA.OFF</i> | | | Seal switch position | The display will show whether the seal switch is in the ON or Off position. This parameter can't be changed within the software. |
| <i>Zero</i> | | | Zero point calibration | Only do zero point calibration, then go to CAL.END to end (only need where a zero shift has occurred). |

| CAL | | | | | |
|----------------|---------------|--------------------------|--|---|--|
| Submenu1 | Submenu2 | Option | Parameter Description | Comment | |
| <i>L I N E</i> | <i>CAL.P0</i> | | Line calibration point0 | Do zero point calibration. This point can't be omitted. | |
| | <i>CAL.P1</i> | | Line calibration point1 | First weight point calibration. This point can't be omitted and standard weight must be over 10%FS. | |
| | <i>END.Y</i> | <i>YES</i> | End calibration? | | YES=go to CAL.END to end NO=go to do next point calibration |
| | | <i>NO</i> | | | |
| | <i>CAL.P2</i> | | Line calibration point2 | Second weight point calibration. Standard weight must be over 10%FS and be larger than it in CAL.P1. This point can be omitted. | |
| | <i>END.Y</i> | <i>YES</i> | End calibration? | | YES=go to CAL.END to end NO=go to do next point calibration |
| | | <i>NO</i> | | | |
| <i>CAL.P3</i> | | Line calibration point3: | Third weight point calibration. Standard weight must be over 10%FS and be larger than it in CAL.P2, this point can be omitted. | | |
| <i>GEO</i> | <i>Code</i> | <i>00-70</i> | Select geographical position | Code 00-70 | |
| | <i>GrAVt</i> | <i>9.76 183-9.99999</i> | Input gravity of user location | | |
| <i>INPUT</i> | | | Input or view calibration parameter values | Only used to copy calibration parameters from one scale to a new scale. | |

5.3.4 MISC Menu



Figure 5.4 MISC Menu Chart

The figure above is an illustration of the available menus with the MISC menu. There are no programming choices within this menu. Refer to [Table 5.5](#) for explanations of the menu choices.

Table 5.5 MISC Menu Choices and Explanations

| MISC | |
|-------------|--|
| Submenu1 | Remark |
| <i>CodE</i> | Display A/D counts = approximately 100,000 counts per mV |
| <i>ūoL</i> | Display voltage; calibrate voltage; set full charged voltage and low battery voltage |
| <i>ūEr</i> | Display firmware version |

5.3.5 TEST Menu




Figure 5.5 TEST Menu Chart

The figure above is an illustration of the available menus with the TEST menu. There are no programming choices within this menu. Refer to [Table 5.6](#) for explanations of the menu choices.

Table 5.6 TEST Menu Choices and Explanations

| TEST | |
|---------------|------------------------|
| Submenu1 | Remark |
| <i>dSP.tS</i> | Test LCD |
| <i>Cñlrđ</i> | Test COM1 receiving |
| <i>Cñltd</i> | Test COM1 transmitting |
| <i>Cñ2rd</i> | Test COM2 receiving |
| <i>Cñ2td</i> | Test COM2 transmitting |
| <i>KEY.tS</i> | Test keys and buzzer |

5.4 Exit the Setup Menu

1. Power off the indicator by pressing and holding the **[ON/OFF]** key.
2. Turn the indicator back on by pressing the **[ON/OFF]** key. The display will go through a digit check, then settle into the normal operating mode. All front panel keys will now return to their normal mode of operation.

6 Calibration

The configuration/calibration button must be pushed in order to calibrate the scale. Refer to Chapter 8 for details on push button location.



NOTE: More than 10% of the full scale weight is needed for calibration.



NOTE: Press the [ON/OFF] key to return to the last sub-menu.

6.1 Enter the Calibration Mode

1. Access the setup mode by pressing the **[HOLD]+[ON/OFF]** key for 3 seconds.
2. Use the **[HOLD]** key to select the CAL menu.
3. Press the **[TARE]** key to enter the calibration mode.
- 3a. After entering this mode, the number of calibrations will be shown first. This number will be increment one digit after every calibration and calibration data saved. This counter can't be modified or erased. It counts from 0000 to 9999, when 9999 is reached, the counter starts over at 0000.
4. After the counter number was displayed, it will show "CAL.OFF" or "CAL.ON" which depends on whether the sealed calibration switch is OFF or ON. **If the switch is OFF, the following steps can be done, but the result will not be saved.**
5. Press the **[TARE]** key to go to next step.

6.1.1 Zero Point

1. When **Err** is displayed, press the **[UNIT]** key to select Zero Point calibration.
2. Once ZERO is selected, remove all weight on the scale.
3. Press **[TARE]** to confirm.
4. The ZERO will flash while capturing the zero point. After getting reasonable data, it automatically saves the change and exits to the weigh mode.

6.1.2 Linearity

The scale linearity can be calibrated with a zero reference and a full scale reference or multiple linearity weight values. The linearity calibration is determined by the settings in the CAL-LINE parameter.

1. When LINE is selected, press the **[TARE]** key to enter linearity calibration.
2. *CAL.P0* will be displayed with a zero value. Remove all weight on the scale and then press the **[TARE]** key to confirm zero point calibration. The zero weight will flash while capturing the zero point. After getting the reasonable zero-point data, the zero weight will become steady.
3. The first default standard weight is displayed after *CAL.P1* being shown. Put the corresponding weight (more than 10%FS weight) onto scale. The default standard weight is 100%FS.
4. Use the **[HOLD]** and **[UNIT]** keys to input the value of the loaded weight.
5. Press the **[TARE]** key to confirm.
- 5a. The indicator will flash the input standard weight. When the weight becomes steady the indicator will automatically go to next step. If this point can't be calibrated correctly *CAL.ERR* will be displayed. It is possible the weight load onto scale is too small or the input data is incorrect. Repeat the previous steps.
6. When *End.Y* is shown and the y is flashing, it is waiting to exit calibration or go on next calibration point. Use the **[UNIT]** key to select yes or no.
7. Press the **[TARE]** key to confirm.
- 7a. If yes is selected, the calibration will be saved and exit to the weigh mode.
- 7b. If no is selected, it will go to next step.
8. When 100% of the full scale weight is displayed after *CAL.P2* is shown, it will be calibrated on standard weight for the second point.
9. Use the **[HOLD]** and **[UNIT]** keys to input the value of the loaded weight (more than 10% FS weight, and larger than the weight used on CAL.P1) onto scale.
10. When *End.Y* is shown and the y is flashing, it is waiting to exit calibration or go on next calibration point. Use the **[UNIT]** key to select yes or no.
11. Press the **[TARE]** key to confirm.
12. When 100% of the full scale weight is displayed after *CAL.P3* is shown, it will be calibrated on standard weight for the third point.
13. Use the **[HOLD]** and **[UNIT]** keys to input the value of the loaded weight (more than 10% FS weight, and larger than the weight used on CAL.P2) onto scale.
14. When *End.Y* is shown and the y is flashing, it is waiting to exit calibration or go on next calibration point. Use the **[UNIT]** key to select yes or no.
15. Press the **[TARE]** key to confirm.
16. When calibration is complete *CAL.END* will be displayed. The indicator will re-start and go back to the weigh mode.

6.2 Geographical Adjustment

1. When GEO is selected, press the **[TARE]** key to enter Geographical Adjustment.
2. When $[odE]$ is displayed, press the **[UNIT]** key to select geographical position code or input user local gravity value directly.
3. When CODE is selected, choose the position code of the scale being used (00-70) according to the elevation and latitude from [Table 6.1](#) by using the **[HOLD]** and **[UNIT]** keys.
4. Press **[TARE]** key to confirm.



CAUTION! Only an authorized manufacturer representative or certified verification personnel may make these changes. Changing the Geographical setting alters the calibration values!

Table 6.1 Location Code For Elevation and Latitude

| Elevation (km) | 0 | 0.2 | 0.4 | 0.6 | 0.8 | 1 | 1.2 | 1.4 | 1.6 | 1.8 | 2 | 2.2 | 2.4 | 2.6 | 2.8 | 3 | 3.2 | 3.4 | 3.6 | 3.8 | 4 | 4.2 | 4.4 | 4.6 | 4.8 | 5 | 5.2 | 5.4 | 5.6 | 5.8 | 6 | | |
|----------------|----|-----|-----|-----|-----|----|-----|-----|-----|-----|----|-----|-----|-----|-----|----|-----|-----|-----|-----|----|-----|-----|-----|-----|----|-----|-----|-----|-----|----|--|--|
| Latitude | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 19 | 18 | 17 | 17 | 16 | 15 | 14 | 14 | 14 | 13 | 12 | 12 | 11 | 11 | 10 | 9 | 9 | 8 | 8 | 7 | 6 | 6 | 5 | 4 | 4 | 3 | 3 | 2 | 1 | 1 | 0 | | |
| 3 | 19 | 18 | 17 | 17 | 16 | 15 | 14 | 14 | 13 | 12 | 12 | 11 | 11 | 11 | 10 | 9 | 9 | 8 | 8 | 7 | 6 | 6 | 5 | 4 | 4 | 3 | 3 | 2 | 1 | 1 | 0 | | |
| 6 | 19 | 18 | 18 | 17 | 17 | 16 | 15 | 14 | 14 | 13 | 12 | 12 | 12 | 11 | 10 | 10 | 9 | 9 | 8 | 7 | 7 | 6 | 6 | 5 | 4 | 4 | 3 | 2 | 2 | 1 | 1 | | |
| 9 | 20 | 19 | 19 | 18 | 17 | 16 | 15 | 14 | 14 | 13 | 12 | 12 | 12 | 11 | 11 | 10 | 10 | 9 | 9 | 8 | 7 | 7 | 6 | 6 | 5 | 4 | 4 | 3 | 2 | 2 | 1 | | |
| 12 | 21 | 20 | 20 | 19 | 18 | 17 | 16 | 16 | 15 | 14 | 13 | 13 | 13 | 12 | 11 | 11 | 10 | 10 | 9 | 8 | 8 | 7 | 7 | 6 | 5 | 4 | 4 | 3 | 2 | 2 | 1 | | |
| 15 | 22 | 21 | 21 | 20 | 20 | 19 | 18 | 18 | 17 | 16 | 16 | 15 | 15 | 14 | 13 | 13 | 12 | 11 | 11 | 10 | 10 | 9 | 8 | 8 | 7 | 7 | 6 | 5 | 4 | 3 | 2 | | |
| 18 | 23 | 23 | 22 | 22 | 21 | 20 | 19 | 19 | 18 | 17 | 17 | 16 | 16 | 15 | 14 | 14 | 13 | 12 | 12 | 11 | 11 | 10 | 10 | 9 | 9 | 8 | 7 | 7 | 6 | 5 | 4 | | |
| 21 | 25 | 25 | 24 | 23 | 23 | 22 | 21 | 21 | 20 | 20 | 19 | 18 | 18 | 17 | 16 | 16 | 15 | 14 | 13 | 13 | 12 | 12 | 11 | 10 | 10 | 9 | 8 | 8 | 7 | 6 | 5 | | |
| 24 | 27 | 26 | 26 | 25 | 25 | 24 | 23 | 23 | 22 | 21 | 21 | 20 | 20 | 19 | 18 | 18 | 17 | 16 | 15 | 14 | 13 | 13 | 12 | 11 | 10 | 10 | 9 | 8 | 7 | 6 | 5 | | |
| 27 | 29 | 29 | 28 | 27 | 27 | 26 | 25 | 24 | 24 | 23 | 22 | 22 | 21 | 21 | 20 | 19 | 19 | 18 | 17 | 17 | 16 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | | |
| 30 | 31 | 31 | 30 | 30 | 29 | 28 | 27 | 26 | 26 | 25 | 25 | 24 | 23 | 23 | 22 | 22 | 21 | 20 | 20 | 19 | 18 | 18 | 17 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | | |
| 33 | 34 | 33 | 33 | 32 | 31 | 31 | 30 | 30 | 29 | 28 | 28 | 27 | 26 | 26 | 25 | 24 | 23 | 23 | 22 | 21 | 21 | 20 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | | |
| 36 | 36 | 36 | 35 | 34 | 34 | 33 | 33 | 32 | 31 | 31 | 30 | 30 | 29 | 28 | 28 | 27 | 26 | 25 | 24 | 24 | 23 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | | |
| 39 | 39 | 38 | 38 | 37 | 36 | 35 | 35 | 34 | 33 | 33 | 32 | 32 | 31 | 31 | 30 | 29 | 29 | 28 | 28 | 27 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | | |
| 42 | 42 | 41 | 40 | 40 | 39 | 38 | 37 | 37 | 36 | 35 | 35 | 34 | 34 | 33 | 33 | 32 | 31 | 31 | 30 | 29 | 29 | 28 | 27 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | | |
| 45 | 44 | 44 | 43 | 42 | 42 | 41 | 41 | 40 | 39 | 39 | 38 | 38 | 37 | 36 | 35 | 34 | 34 | 33 | 33 | 32 | 31 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | | |
| 48 | 47 | 46 | 46 | 45 | 45 | 44 | 43 | 43 | 42 | 41 | 41 | 40 | 40 | 39 | 38 | 38 | 37 | 36 | 35 | 35 | 34 | 33 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | | |
| 51 | 50 | 49 | 48 | 48 | 47 | 46 | 45 | 45 | 44 | 44 | 43 | 42 | 42 | 41 | 40 | 40 | 39 | 38 | 37 | 36 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | | |
| 54 | 52 | 52 | 51 | 50 | 49 | 49 | 48 | 47 | 47 | 46 | 46 | 45 | 44 | 43 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | | |
| 57 | 55 | 54 | 54 | 53 | 52 | 51 | 51 | 50 | 49 | 49 | 48 | 47 | 47 | 46 | 45 | 44 | 43 | 43 | 42 | 41 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | | |
| 60 | 57 | 57 | 56 | 55 | 55 | 54 | 53 | 52 | 52 | 51 | 51 | 50 | 49 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | | |
| 63 | 60 | 59 | 58 | 58 | 57 | 56 | 55 | 55 | 54 | 53 | 52 | 52 | 51 | 50 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | 34 | | |
| 66 | 62 | 61 | 60 | 60 | 59 | 58 | 57 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | 37 | 36 | 35 | | |
| 69 | 64 | 63 | 62 | 62 | 61 | 61 | 60 | 59 | 59 | 58 | 57 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | 38 | | |
| 72 | 65 | 65 | 64 | 63 | 63 | 62 | 61 | 60 | 60 | 59 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | 39 | | |
| 75 | 67 | 66 | 66 | 65 | 64 | 64 | 63 | 62 | 61 | 61 | 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 | | |
| 78 | 68 | 67 | 67 | 66 | 65 | 64 | 64 | 63 | 62 | 61 | 61 | 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | | |
| 81 | 69 | 68 | 68 | 67 | 66 | 65 | 64 | 63 | 63 | 62 | 61 | 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | | |
| 84 | 70 | 69 | 68 | 68 | 67 | 66 | 65 | 64 | 64 | 63 | 62 | 61 | 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | | |
| 87 | 70 | 70 | 69 | 68 | 68 | 67 | 66 | 65 | 64 | 63 | 62 | 61 | 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | | |
| 90 | 70 | 70 | 69 | 68 | 68 | 67 | 66 | 65 | 64 | 63 | 62 | 61 | 60 | 59 | 58 | 57 | 56 | 55 | 54 | 53 | 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | | |

6.3 Gravity Value

1. When $\overline{G-R-A-V-E}$ is selected, press the **[HOLD]** and **[UNIT]** keys to input the gravity value of the position that scale is used (9.76183-9.99999).
2. Press the **[TARE]** key to confirm.



NOTE: Only an authorized manufacture representative or certified verification personnel may make these changes.

6.4 Input or View Calibration

1. When $\overline{I-N-P-U-T}$ is selected, press the **[TARE]** key to enter Input calibration parameter values that were previously received or view current calibration parameter values.

All parameters regarding calibration are divided to 12 pages and are displayed on LCD by "nn:xxxx" format ("nn" is a decimal number of page, "xxxx" is an hexadecimal value of parameter. (e.g. 02:85E2).

- 01-02 pages: zero code
 - 03-04 pages: standard weight of CAL.P1
 - 05-06 pages: codes of CAL.P1
 - 07-08 pages: standard weight of CAL.P2
 - 09-10 pages: codes of CAL.P2
 - 11-12 pages: full capacity net code
2. When no digits are blinking on the display, this means calibration parameters value are being viewed. Use the **[HOLD]** key to view the next page.
 3. When parameter values are being viewed, press the **[HOLD]** key for more than 3 seconds to modify.
 4. When first digit is blinking, this means the value is being modified. Press the **[HOLD]** key to make next digit flash (if current flashing position is the last one the next page value will be shown).
 5. Press the **[HOLD]** and **[UNIT]** keys to input the number.
 6. Press the **[TARE]** key to confirm.
 7. After the indicator gets all needed data, it will calculate and store all calibration parameters into EEPROM or after finishing calibration, it will display $\overline{CAL.Pd}$.
 8. The scale will re-start and go back to original mode.

6.5 Weight Fine-tune

With this function, the user can adjust displayed weight a little without the need of standard weight. But please note:

- The scale must have been calibrated previously
 - The range of adjustment is "(current displayed weight) x (0.9-1.1)". This means the range is about $\pm 10\%$
 - The CONFIG-REGUL=NONE and CONFIG-FUNC-WT.ADJ=YES must be set.
1. To enter this mode, turn on indicator. After the indicator displays a 0 weight, place weight onto scale. The indicator will display the weight.
 2. Press down **[TARE]** and **[ZERO]** at same time until the first digit flashes, this means indicator has entered into "weight fine-tune" mode.
 3. Use the arrow keys to input correct weight.
 4. Press the **[TARE]** key to confirm. The active correct weight will be displayed. The displayed weight will be adjusted by this ratio (130.0/1234.5). The ratio will be active until the next modification.
 5. Recalibrate the scale or use the Weight Fine Tune method to readjust the ration.

6.6 Display ADC Output Code

In this mode, you can examine the stability of weighing system and increment the ADC output code corresponding to the loaded weight. Please note the following:

- The increment of ADC code for full scale weight must be larger or equal to 10 times of selected display division. Otherwise, the calibration cannot be properly completed.
 - e.g. The display division is 0.1kg. Load 100kg standard weight on the platform, the increment of ADC code should be at least more than $10 \times 100\text{kg} / 0.1\text{kg} = 10 \times 1000 = 10000$. In this case, the scale can be calibrated. Otherwise, a smaller division needs to be chosen.
 - The variation of the ADC code should be small. Otherwise, the calibration cannot be properly completed.
1. From the weigh mode press the **[HOLD] + [ON/OFF]** key until `CONF` is shown.
 2. Use the **[UNIT]** and **[TARE]** keys to go to MISC - Code.
 3. Press the **[TARE]** key to enter this mode and display the ADC output raw code.
 4. Press the **[TARE]** key to set the current code as a reference zero and then display net code
 5. Press **[TARE]** again to clear this reference and display gross code.
 6. In this mode, press the **[UNIT]** key to select displaying code that has been filtered by no-filter, filter1 and filter2.
 7. Press the **[ON/OFF]** key to exit this mode.

7 Serial Communication

7.1 Communication Settings

1. Power on the indicator by pressing and holding the **[ON/OFF]** key. The display will go through a display test then go into regular weigh mode.
2. Press the **[HOLD] + [ON/OFF]** key for 3 seconds. The indicator shows `CONF` to indicate that you are in Setup Menu mode.
3. Press the **[UNIT]** key until the indicator display shows `USER`.
4. Press the **[TARE]** key and the indicator display shows `RESET`.
5. Press the **[UNIT]** key until you see the com port you are using for your software; `COM1` (USB port) or `COM2` (serial port)
6. Press the **[TARE]** key to select the desired com port.
7. The indicator's display shows `baudr`. Press the **[TARE]** key go into the baud rate setting and confirm it is appropriate baud rate for your software. To toggle to another baud rate setting, press the **[UNIT]** key until the one is displayed. (i.e. 1200, 2400, 4800, 9600, 19200, 38400)
8. Press the **[TARE]** key and the display shows `baudr`. Press the **[UNIT]** key and the display shows `bitfmt`. Press the **[TARE]** key to go into the setting and confirm it is the appropriate bit format for your software. To select another bit format setting, press the **[UNIT]** key until the desired selection is displayed. (i.e. 8n1, 7E1, 7O1)
9. Press the **[TARE]** key and the display shows `bitfmt`. Press the **[UNIT]** key until the display shows `LYOUT`.
10. Press the **[TARE]** key to go into your selection and press the **[UNIT]** key until the display shows correct protocol needed for your software. *Most common as follows `SCPD1` = NCI protocol, `SCPD2` = ECR protocol, `SCPD3` = Toledo 8213 or `ibn` = IBM protocol.
11. Press the **[TARE]** key and `LYOUT` will be displayed.
12. Press the **[ZERO]** key to display the com port that you were changing.
13. Press the **[UNIT]** key until the display shows `OTHER`.
14. Press the **[TARE]** key until the display shows `PLDRG`.
15. Press the **[UNIT]** key until `LEGACY` is displayed.
16. Press the **[TARE]** key and a number will be displayed.
17. Press the **[UNIT]** key until a `2` is displayed.
18. Press the **[TARE]** key and `LEGACY` will be displayed.
19. Press and release the **[ZERO/ON/OFF]** key until you are all the way out of the Setup Menu mode and into the Normal Weigh mode.
20. Test scale with software. If scale fails communication, contact Brecknell Tech Support at 800-242-2807 for further testing.

7.2 Com Port 1

COM1 is a USB port used as a virtual RS-232 port. Communication wires come from the USB connector and TXD0, RXD0 and GND.

7.3 Com Port 2

COM2 is a RS-232 bi-directional port. Communication wires are connected to the RS-232 connector using TXD1, RXD1 and GND. Refer to [page 10](#) for connection details.

7.4 Protocol

The baud rate and byte format is set by USER-COM-BUD.RT and USER-COM-BT.FMT.

Responses to serial commands will be immediate or within one weight measure cycle of the scale. One second should be adequate for use as a time-out value by remote (controlling) device.

7.5 Transaction String

The length of each item in a transaction string:

- Reading data --- 6 bytes
- Data polarity ----1 byte: "-" for negative, and followed the first digit; " " for positive.
- Decimal point ---1 byte: "."
- Measure unit ----1-5 bytes:" lb", " kg", "lb:oz", "pcs", "%". Units are always lower case, left aligned
- Current status-- 4 bytes
 - If the weight is over capacity, the scale will return eight "^" characters (the field of polarity, decimal point, weight data is filled by "^").
 - If the weight is under capacity, it will return eight "_" characters (the field of polarity, decimal point, and weight data is filled by "_").
 - If the zero point is error, it will return eight "-" characters (the field of polarity, decimal point, and weight data is filled by "-").

Useless leading 0 before digits is suppressed. Reading weight is right aligned.

Table 7.1 Symbols Used

| | |
|---|-------------------------------------|
| <LF> | Line Feed character (hex 0AH) |
| <CR> | Carriage Return character (hex 0DH) |
| <ETX> | End of Text character (hex 03H) |
| <SP> | Space (hex 20H) |
| H ₁ H ₂ H ₃ H ₄ | Four current status bytes |
| <P> | Polarity character: "-" or " " |

| | |
|---|---|
| W₁---W₆ | Reading data, 1-6 bytes (six digits) |
| <DP> | Decimal point |
| U₁U₂ U₃U₄U₅ | Measure units, kg, lb, lb:oz, % or pcs; 2-5 bytes |
| <Add> | Address of scale; 2 bytes (00-99) |
| <Prompt> | Prompt characters of output content; max. 11bytes |

Table 7.2 Bit Definition of H₁H₂H₃ H₄

| Bit | Byte 1 (H ₁) | Byte 2 (H ₂) | Byte 3 (H ₃) | Byte 4 (H ₄) |
|-----|--------------------------|--------------------------|--|---|
| 0 | 0 = stable | 0 = not under capacity | 00 = compare disable 01 = lower limit 10 = ok 11= upper limit | 00 = normal weighing 01 = count weighing 10 = percent weighing 11 = other mode |
| | 1 = not stable | 1 = under capacity | | |
| 1 | 0 = not at zero point | 0 = not over capacity | | |
| | 1 = at zero point | 1 = over capacity | | |
| 2 | 0 = RAM ok | 0 = ROM ok | 0 = gross weight | 0 = not in HOLD |
| | 1 = RAM error | 1 = ROM error | 1 = net weight | 1 = in HOLD |
| 3 | 0 = eeprom OK | 0 = calibration ok | 0 = initial zero ok | 0 = battery ok |
| | 1 = eeprom error | 1 =calibration error | 1 = initial zero error | 1 = low battery |
| 4 | always 1 | always 1 | always 1 | always 1 |
| 5 | always 1 | always 1 | always 1 | always 1 |
| 6 | always 0 | always 1 | always 1 | always 0 |
| 7 | parity | Parity | parity | Parity |

7.6 Commands and Response

7.6.1 Parameter NCI-SCP01

Set the USER-COM-LYOUT parameter to *5[PD]I*.

Command: W<CR> (57h 0dh), request current reading

| Response |
|--|
| <LF>^^^^^^U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX>---over capacity |
| <LF>_ _ _ _ _ U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX>---under capacity |
| <LF> - - - - - U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX>---zero-point error |
| Note: U ₁ U ₂ U ₃ U ₄ U ₅ is 1,2,3 or 5 bytes according to current unit: kg, lb, pcs, g, oz, lb:oz |
| <LF><P>W ₁ W ₂ W ₃ W ₄ W ₅ <DP>W ₆ U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX>---normal data |
| Note: (1) The decimal point position is determined by CONFIG-PRIM.D (2) If current unit is "lb:oz", the format will be similar with following: |
| <LF><P>W ₁ W ₂ W ₃ lb<SP>W ₄ W ₅ <DP>W ₆ oz<CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

Command: S<CR> (53h 0dh), request current status

| Response |
|--|
| <LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

Command: Z<CR> (5ah 0dh)

| Response |
|--|
| Zero function is activated (simulate ZERO key) and it returns to current scale status. |
| <LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

If ZERO function cannot be activated, it will return to current scale status.

Command: T<CR> (54h 0dh)

| Response |
|--|
| TARE function is activated (simulate TARE key), and then returns scale status. |
| <LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

If TARE function cannot be activated, it will return to current scale status.

Command: U<CR> (55h 0dh)

| Response |
|--|
| Changes units of measure (simulate UNIT key) and return scale status with new units. The new measure unit should be allowed to use |
| <LF> U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

Command: L<CR> (4ch 0dh)

| Response |
|---|
| If Hold function can be activated, it will enable/disable hold function (simulate HOLD key) and returns scale status. |
| <LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

Command: X<CR> (58h 0dh)

| Response |
|---|
| Power off the scale. Same as pressing the ON/OFF key to turn off the scale. |

Command: all others

| Response |
|----------------------|
| Unrecognized command |
| <LF>? <CR><ETX> |

Table 7.3 Summary of Command and Response:

| Command | | Response |
|---------|-------|--|
| ASCII | HEX | |
| W<CR> | 57 0d | Read scale weight: <LF>^U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX>---over capacity <LF> _____ U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX>---under capacity <LF>----- U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> H ₁ H ₂ H ₃ H ₄ <CR><ETX>---zero-point error <LF><P>W ₁ W ₂ W ₃ W ₄ W ₅ <DP>W ₆ U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF>H ₁ H ₂ H ₃ H ₄ <CR><ETX>---normal data |
| S<CR> | 53 0d | <LF>H ₁ H ₂ H ₃ H ₄ <CR><ETX>; read scale status |
| Z<CR> | 5a 0d | <LF>H ₁ H ₂ H ₃ H ₄ <CR><ETX>; simulate ZERO key |
| T<CR> | 54 0d | <LF>H ₁ H ₂ H ₃ H ₄ <CR><ETX>; simulate TARE key |
| U<CR> | 55 0d | <LF> U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF>H ₁ H ₂ H ₃ H ₄ <CR><ETX>; simulate UNIT key |
| L<CR> | 4c 0d | <LF>H ₁ H ₂ H ₃ H ₄ <CR><ETX>; simulate HOLD key |
| X<CR> | 58 0d | power off the scale, simulate OFF key |
| others | | <LF>? <CR><ETX> |

7.6.2 Parameter ECR-SCP02

Set the USER-COM-LYOUT parameter to *5[CP02*.

Command: W<CR> (57h 0dh), request current reading

| Response |
|--|
| <LF>^^^^^^U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---over capacity |
| <LF>_ _ _ _ _ U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---under capacity |
| <LF> - - - - - U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---zero-point error |
| Note: U ₁ U ₂ U ₃ U ₄ U ₅ is 1,2,3 or 5 bytes according to current unit: kg, lb, pcs, g, oz, lb:oz |
| <LF><P>W ₁ W ₂ W ₃ W ₄ W ₅ <DP>W ₆ U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---normal data |
| Note: (1) The decimal point position is determined by CONFIG-PRIM.D (2) If current unit is "lb:oz", the format will be similar with following: |
| <LF><P>W ₁ W ₂ W ₃ lb<SP>W ₄ W ₅ <DP>W ₆ oz<CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

Command: S<CR> (53h 0dh), request current status

| Response |
|--|
| <LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

Command: Z<CR> (5ah 0dh)

| Response |
|--|
| Zero function is activated (simulate ZERO key) and it returns to current scale status. |
| <LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

If ZERO function cannot be activated, it will return to current scale status.

Command: U<CR> (55h 0dh)

| Response |
|--|
| Changes units of measure (simulate UNIT key) and return scale status with new units. The new measure unit should be allowed to use |
| <LF> U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX> |

Command: u<CR> (75h 0dh)

| Response |
|--|
| Returns current units-of-measure as a single numeric character. |
| <LF>x<CR><ETX> |
| x = 1 = grams 2 = kilograms 3 = ounces 4 = pounds 5 = pounds - ounces |

Command: A<CR> (41h 0dh)

| Response |
|--|
| Returns scale OPOS capabilities as a string of five flag characters. |
| <LF>vwxyz<CR><ETX> |
| v = T - scale has a weight display (CapDisplay) v = F - scale does not have a weight display |
| w = T -scale has a text display (CapDisplayText) w = F -scale does not have a text display |
| x = T -scale can calculate unit price (CapPriceCalculating) x = F -scale cannot calculate unit price |
| y = T -scale allows setting tare value (CapTareWeight) y = F -scale does not allow setting tare value |
| z = T -scale may be zeroed (CapZeroScale) z = F -scale cannot be zeroed |

Command: m<CR> (6dh 0dh)

| Response |
|---|
| Returns current maximum weight supported by the scale as a string value, without decimal point and in the currently enabled unit of measure. |
| <LF>XX<CR><ETX> |

Command: <ENQ><CR> (05h 0dh)

| Response |
|---|
| Depends on the scale and protocol. |
| <LF>OPOS<CR><ETX> OPOS - enabled scale |

Command: all others

| Response |
|----------------------|
| Unrecognized command |
| <LF>? <CR><ETX> |

Table 7.4 Summary of Command and Response:

| Command | | Response |
|-----------|-------|---|
| ASCII | HEX | |
| W<CR> | 57 0d | Read scale weight: <LF>^U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF>S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---over capacity <LF>_____U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF>S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---under capacity <LF>----- U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---zero-point error <LF><P>W ₁ W ₂ W ₃ W ₄ W ₅ <DP>W ₆ U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>---normal data |
| S<CR> | 53 0d | <LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>; read scale status |
| Z<CR> | 5a 0d | <LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>; simulate ZERO key |
| U<CR> | 55 0d | <LF>U ₁ U ₂ U ₃ U ₄ U ₅ <CR><LF> S H ₁ H ₂ H ₃ H ₄ <CR><ETX>; simulate UNIT key |
| u<CR> | 75 0d | <LF> x<CR><ETX> |
| A<CR> | 41 0d | <LF>vwxyz<CR><ETX> |
| m<CR> | 6d 0d | <LF>xx<CR><ETX> |
| <ENQ><CR> | 05 0d | <LF>OPOS<CR><ETX> |
| L<CR> | 4c 0d | <LF>H ₁ H ₂ H ₃ H ₄ <CR><ETX>; simulate HOLD key |
| X<CR> | 58 0d | Power off the scale, simulate OFF key |
| others | | <LF>? <CR><ETX> |

7.6.3 Parameter 8213-SCP03

Set the USER-COM-LYOUT parameter to `5[CP03]`.

Command: W (57h), request current reading

| Response |
|---|
| <STX>W ₁ W ₂ <dp>W ₃ W ₄ W ₅ <CR>---normal data |
| Note: (1) The decimal point position is determined by CONFIG-PRIM.D (2) If current unit is "lb:oz", the format will be similar with following: |
| <STX>W ₁ W ₂ W ₃ lbW ₄ W ₅ <dp>W ₆ oz<CR> |

Command: Z (5ah)

| Response |
|--|
| Zero function is activated (simulate ZERO key) and it returns to current scale status. |
| <STX>?[status]<CR> |

If ZERO function cannot be activated, it will return to current scale status.

Table 7.5 Status Bits

| Bit | Status |
|-----|--|
| 0 | 0 = not in motion |
| | 1 = in motion |
| 1 | 0 = not over capacity |
| | 1 = over capacity |
| 2 | 0 = not under zero (positive polarity) |
| | 1 = under zero (negative polarity) |
| 3 | 0 = inside zero capture range |
| | 1 = outside zero capture range |
| 4 | 0 = not center of zero |
| | 1 = center of zero |
| 5 | always 1 |
| 6 | always 1 |
| 7 | parity |

Command: H (48h)

| Response |
|---|
| Send high resolution weight dat (x10) |
| <STX>W ₁ W ₂ <dp>W ₃ W ₄ W ₅ <CR>---normal data |
| Note: (1) The decimal point position is determined by CONFIG-PRIM.D (2) If current unit is "lb:oz", the format will be similar with following: |
| <STX>W ₁ W ₂ W ₃ lbW ₄ W ₅ W ₆ <dp>W ₇ oz<CR> |

Command: A (41h)

| Response |
|--|
| Scale initiates a test of RAM, ROM and NOVRAM. Places the result into confidence test status byte for future interrogation by the host. It also returns acknowledgement. |
| <STX>?<CR> |

Command: B (42h)

| Response |
|---|
| Send confidence test result status byte of previously performed test (Command A). |
| <STX>[confidence]<CR> |

| Bit | Confidence |
|-----|-------------------------|
| 0 | always 0 |
| 1 | 0= NOVRAM Test Pass |
| | 1= NOVRAM Test Fail |
| 2 | always 0 |
| 3 | 0= RAM Test Pass |
| | 1= RAM Test Fail |
| 4 | 0= ROM Test Pass |
| | 1= ROM Test Fail |
| 5 | always 0 |
| 6 | 0= New Status Read |
| | 1= New Status Available |
| 7 | parity |

Command: E (45h)

| Response |
|---|
| Scale is placed in echo mode. All subsequent characters (except F) are not treated as commands. These characters are echoed back to the host. |
| <STX>E<CR> |

Command: F (46h)

| Response |
|--|
| Scale is taken out of echo mode. All subsequent characters are commands. |
| <STX>F<CR> |

Command: all others

| Response |
|----------------------|
| Unrecognized command |
| <STX>?[status]<CR> |

Table 7.6 Summary of Command and Response:

| Command | | Response |
|---------|-----|--|
| ASCII | HEX | |
| W | 57 | Read scale weight: <STX>W ₁ W ₂ W ₃ W ₄ <DP>W ₅ U ₁ U ₂ U ₃ U ₄ U ₅ <CR>---normal data |
| Z | 5a | <STX>?[status]<CR> |
| H | 48 | 1. normal data <STX>W ₁ W ₂ <dp>W ₃ W ₄ W ₅ W ₆ <CR> -- weight data (x10) 2. if current weight is invalid <STX>?<Status Byte><CR> |
| A | 41 | <STX>?<CR> |
| B | 42 | <STX>[confidence]<CR?> |
| E | 45 | <STX>E<CR> |
| F | 46 | <STX>F<CR> |
| others | | <STX>?[status]<CR> |

7.6.4 Parameter Multi

Set the USER-COM-LYOUT parameter to $\bar{n}U\bar{L}L$.

| Output string frame |
|--|
| Command: W<CR> (57h 0dh), request current reading |
| <LF><Prompt><p>W ₁ W ₂ W ₃ W ₄ W ₅ <DP>W ₆ U ₁ U ₂ U ₃ U ₄ U ₅ <CR> |
| Line number and content are determined by setting of USER-OUT-xxxx |
| <LF><Prompt>H ₁ H ₂ H ₃ H ₄ <CR> |
| USER-OUT-STATUS is set to YES |
| C<CR> |
| USER-OUT1/2-LINE is set to LINE1/2/3/4 |
| ----- |
| The number of lank lines is determined by USER-OUT-LINE setting |
| <LF> |
| (1) The decimal point position is determined by CONFIG-PRIM.D (2) The unit position and bytes are determined by which current unit is used (3) The details of <Prompt> refer to the content in User submenu (4) In HOLD mode, if ADC conversion speed is set to high speed (80Hz) and USER-COM-LYOUT is set to MULTI, the output from COM may be slower than the data processed by the indicator. For "real time" data, select fewer output contents and set a higher baud rate for C<CR> --- USER-OUT-LINE is set to LINE1/2/3/4 |
| <LF> --- |
| ---The number of blank lines is determined by USER-OUT1/2-LINE setting |
| <ETX> |
| --- Last byte of string frame |

Example Layouts

When USER-OUT-xxxx is set to YES

Weighing Mode:

| | |
|-----------|--------------|
| SCALE ID: | 123456 |
| GROSS: | 123lb 4.56oz |
| TARE: | 11lb 2.22oz |
| NET: | 112lb 2.34oz |
| A/D CODE: | 1234567 |
| VOLTAGE: | 5.7V |
| STATUS: | bpq2 |

Counting Mode:

| | |
|-----------|-----------|
| SCALE ID: | 123456 |
| GROSS: | 1234.55kg |
| TARE: | 12.15kg |
| NET: | 1222.40kg |
| QUANTITY: | 24448pcs |
| PIECE WT: | 0.05kg |
| A/D CODE: | 1234345 |
| VOLTAGE: | 5.7V |
| STATUS: | bpq2 |

7.6.5 Parameter EH-SCP (PS-60)

Set the USER-COM-LYOUT parameter to *EH-SCP*

This protocol is compatible with Toledo PS60 protocol. The baud rate and data format is set by User menu.

Output Status Bit Meaning

Table 7.7 Status Bits

| Bit | Status |
|-----|--|
| 0 | 0 = not in motion |
| | 1 = in motion |
| 1 | 0 = not over capacity |
| | 1 = over capacity |
| 2 | 0 = not under zero (positive polarity) |
| | 1 = under zero (negative polarity) |
| 3 | 0 = inside zero capture range |
| | 1 = outside zero capture range |
| 4 | 0 = not center of zero |
| | 1 = center of zero |
| 5 | always 1 |
| 6 | always 1 |
| 7 | parity |

Summary of Command and Response

| Command | | Response |
|---------|-----|--|
| ASCII | HEX | |
| W | 57 | Read scale weight: <STX>W ₁ W ₂ <DP>W ₃ W ₄ W ₅ <CR>---normal data <STX>?[status]<CR>--if current weight is invalid |
| S | 53 | Read scale status: <STX>?[status]<CR> |
| Z | 5a | Simulate ZERO key: <STX>?[status]<CR> |
| T | 54 | Simulate TARE key: <STX>?[status]<CR> |
| X | 58 | Simulate OFF key: power off the scale |
| others | | Unknown commands: <STX>?[status]<CR> |

7.6.6 Parameter IBM

Set the USER-COM-LYOUT parameter to $ib\bar{n}$.

Command: <US> W (1Fh 57h), request current reading

| Response |
|---|
| <STX>W ₁ W ₂ <dp>W ₃ W ₄ W ₅ <CR>---normal data |
| Note: (1) The decimal point position is determined by CONFIG-PRIM.D (2) If current unit is "lb:oz", the format will be similar with following: |
| <STX>W ₁ W ₂ W ₃ lbW ₄ W ₅ <dp>W ₆ oz<CR> |

Command: <US> Z (1Fh 5ah)

| Response |
|--|
| Zero function is activated (simulate ZERO key) and it returns to current scale status. |
| <STX>?[status]<CR> |

If ZERO function cannot be activated, it will return to current scale status.

Table 7.8 Status Bits

| Bit | Status |
|-----|--|
| 0 | 0 = not in motion |
| | 1 = in motion |
| 1 | 0 = not over capacity |
| | 1 = over capacity |
| 2 | 0 = not under zero (positive polarity) |
| | 1 = under zero (negative polarity) |
| 3 | 0 = inside zero capture range |
| | 1 = outside zero capture range |
| 4 | 0 = not center of zero |
| | 1 = center of zero |
| 5 | always 1 |
| 6 | always 1 |
| 7 | parity |

Command: <US> H (1Fh 48h)

| Response |
|---|
| Send high resolution weight dat (x10) |
| <STX>W ₁ W ₂ <dp>W ₃ W ₄ W ₅ W ₆ <CR>---normal data |
| Note: (1) The decimal point position is determined by CONFIG-PRIM.D (2) If current unit is "lb:oz", the format will be similar with following: |
| <STX>W ₁ W ₂ W ₃ lbW ₄ W ₅ W ₆ <dp>W ₇ oz<CR> |

Command: <US> A (1Fh 41h)

| Response |
|--|
| Scale initiates a test of RAM, ROM and NOVRAM. Places the result into confidence test status byte for future interrogation by the host. It also returns acknowledgement. |
| <STX>?<CR> |

Command: <US> B (1Fh 42h)

| Response |
|---|
| Send confidence test result status byte of previously performed test. |
| <STX>[confidence]<CR> |

| Bit | Confidence |
|-----|-------------------------|
| 0 | always 0 |
| 1 | 0= NOVRAM Test Pass |
| | 1= NOVRAM Test Fail |
| 2 | always 0 |
| 3 | 0= RAM Test Pass |
| | 1= RAM Test Fail |
| 4 | 0= ROM Test Pass |
| | 1= ROM Test Fail |
| 5 | always 0 |
| 6 | 0= New Status Read |
| | 1= New Status Available |
| 7 | parity |

Command: <US> E (1Fh 45h)

| Response |
|---|
| Scale is placed in echo mode. All subsequent characters (except F) are not treated as commands. These characters are echoed back to the host. |
| <STX>E<CR> |

Command: <US> F (1Fh 46h)

| Response |
|--|
| Scale is taken out of echo mode. All subsequent characters are commands. |
| <STX>F<CR> |

Command: all others

| Response |
|----------------------|
| Unrecognized command |
| <STX>?[status]<CR> |

Table 7.9 Summary of Command and Response:

| Command | | Response |
|---------|-------|--|
| ASCII | HEX | |
| <US> W | 1F 57 | 1. normal data <STX>W ₁ W ₂ <dp>W ₃ W ₄ W ₅ <CR> 2. if current weight is invalid <STX>?<Status Byte><CR> |
| <US> Z | 1F 5a | <STX>?[status]<CR> |
| <US> H | 1F 48 | 1. normal data <STX>W ₁ W ₂ <dp>W ₃ W ₄ W ₅ W ₆ <CR> -- weight data (x10) 2. if current weight is invalid <STX>?<Status Byte><CR> |
| <US> A | 1F 41 | <STX>?<CR> |
| <US> B | 1F 42 | <STX>[confidence]<CR?> |
| <US> E | 1F 45 | <STX>E<CR> |
| <US> F | 1F 46 | <STX>F<CR> |
| others | | <STX>?[status]<CR> |

8 Legal for Trade

The 67XXU Model must be configured to meet regulations mandated by local weights and measures authorities.

8.1 Physical Seal

The configuration/calibration push button is used to protect the scale from being configured or calibrated under legal for trade conditions. When set to legal for trade and sealed with a lead seal, the scale can only be configured and calibrated by authorized personnel.

The push button is located under the center screw on the underside of the scale. Remove the center screw. Press the button with a non-metallic object or a #0 phillips screwdriver.



CAUTION!

Do not use a flat blade screwdriver or other small metallic object as this could damage the scale!




Figure 8.1 Physical Seal Location

8.2 Audit Trail Parameters

Two separate incrementing, non-resetable audit trail parameters are used to indicate changes to various parameters or calibration.

8.2.1 View Configuration Counter

1. Press and hold the **[HOLD] + [ON/OFF]** key for 3 seconds. `[OFF]` is displayed.
2. Press the **[TARE]** key to view the configuration counter.
- 2a. The display will briefly show the number of times the configuration has been changed and will save up to 9999. This counter can't be modified or erased. It counts from 0000 to 9999. When 9999 is reached, the counter starts over at 0000. The display will then show whether the configuration switch is on (`[F.ON]`) or (`[F.OFF]`) off.

To Exit:

1. Press the **[ON/OFF]** key twice. `EXIT` is displayed.
2. Press the **[TARE]** key to return to the working mode.

8.2.2 View Calibration Counter

1. Press and hold the **[HOLD] + [ON/OFF]** key for 3 seconds. `[OFF]` is displayed.
2. Use the **[HOLD]** key to select the CAL menu.
3. Press the **[TARE]** key to enter the calibration mode.
- 3a. After entering this mode, the number of calibrations will be shown first. This number will be increment one digit after every time a calibration has been performed and saved. This counter can't be modified or erased. It counts from 0000 to 9999, when 9999 is reached, the counter starts over at 0000.
4. After the counter number was displayed, it will show "`[A.OFF]`" or "`[AL-ON]`" which depends on whether the sealed calibration switch is OFF or ON. **If the switch is OFF, the following steps can be done, but the result will not be saved.**

To Exit:

1. Press the **[ON/OFF]** key twice. `EXIT` is displayed.
2. Press the **[TARE]** key to return to the working mode.

9 Troubleshooting

This chapter gives explanations on commonly seen errors, display characters and display symbols.

9.1 Display Characters

| ASCII | LCD/LED | ASCII | LCD/LED | ASCII | LCD/LED |
|-------|---------|-------|---------|-------|---------|
| 0 | 0. | A | A. | N | N. |
| 1 | 1. | B | B. | O | O. |
| 2 | 2. | C | C. | P | P. |
| 3 | 3. | D | D. | Q | Q. |
| 4 | 4. | E | E. | R | R. |
| 5 | 5. | F | F. | S | S. |
| 6 | 6. | G | G. | T | T. |
| 7 | 7. | H | H. | U | U. |
| 8 | 8. | I | I. | V | V. |
| 9 | 9. | J | J. | W | W. |
| | | K | K. | X | X. |
| | | L | L. | Y | Y. |
| | | M | M. | Z | Z. |

9.2 Display Symbols

| Symbol | Description |
|-----------------|---|
| \square ---- | Zero is over the setting range |
| \square _____ | Zero point is below the setting range |
| Rd ---- | Signal to ADC is over maximum range |
| Rd _____ | Signal to ADC is below minimum range |
| ----- | Weight is over upper limitation or display data is over limitation |
| ----- | Weight is below lower limitation |
| $EEEE1$ | CONFIG or CAL parameters are not correctly set |
| $EEEE2$ | USER parameter is not correctly set |
| $Lo.bAt$ | Battery voltage is lower than setting |
| $[CAP.- - -$ | Next displaying content is capacity |
| $[CAP.Er$ | Parameters about Capacity is not correct |
| $[CAL.P11$ | Calibration on point (x) |
| $[CAL.oFF$ | Calibration seal switch is on OFF position |
| $[CAL.oN$ | Calibration seal switch is on ON position |
| $[CAL.Er$ | Calibration error, maybe input data or loaded weight is incorrect, unstable, non-linear |
| $[A.END$ | End calibration |
| oFF | Power OFF the indicator |
| $Stt.b.Er$ | Unstable time is larger than setting of USER-OTHER-NLD.RNG |
| $Pr.tAr$ | Preset TARE weight |
| $[o.nP$ | Input COMPARE data mode |
| H, GH | Input HIGH limitation data of Comparison |
| LoY | Input LOW limitation data of Comparison |
| $SPL.Lo$ | Sample load weight of low point. |
| $SPL.H,$ | Sample load weight of high point. |

| Symbol | Description |
|---------------|---|
| <i>SPL.PZ</i> | Sample goods weight to calculate piece weight |
| <i>IN.PCS</i> | Input number of pieces being counted |
| <i>UNL.KG</i> | Unit kg is selected |
| <i>UNL.LB</i> | Unit lb is selected |
| <i>PZL.Er</i> | Piece weight error, sample too small (<0.5d) |

9.3 Error Messages and Troubleshooting

| Symptom | Probable Cause | Remedy |
|---------------|---|---|
| <i>Ad---</i> | Loadcell wires to indicator are incorrectly connected, shorted, opened, ADC or loadcell(s) are damaged. | Make sure wires are ok and correctly connected. Replace loadcell or ADC chip, Service required. |
| <i>Ad---</i> | | |
| <i>0----</i> | Weight reading exceeds Power On Zero limit. | Make sure scale platform is empty. Perform zero calibration. |
| <i>0----</i> | Weight reading below Power On Zero limit. | Install platform on scale. Perform zero calibration. |
| <i>-----</i> | Weight reading exceeds Overload limit or the weight value cannot be displayed in the current unit of measure because it exceeds 6 digits. | Reduce load on scale until weight value can be displayed. Use a more appropriate unit of measure. Re-set some parameters of CONFIG or USER. |
| <i>-----</i> | Weight reading below Under load limit. | Install platform on scale. Perform zero calibration. |
| <i>EEPE1</i> | CONFIG or CAL parameters are not correctly set. | Re-set items in CONFIG, do calibration. |
| <i>EEPE2</i> | USER parameter is not correctly set. | Re-set items in USER. |
| <i>CAPEr</i> | Capacity parameters are not correct. | Set PRIM.N/PRIM.D/SECND.n to correct number, make sure capacity not more than 6 digit. |
| <i>CALEr</i> | Calibration error. Input data or loaded weight is too small, too big, unstable, non-linear. | Input correct data, load correct weight onto platform, Service required. |
| <i>PZL.Er</i> | Piece weight is error, it's too small (<0.5d), The weight on the platform is too small to define a valid reference weight. | Use a greater weight for the sample. |

| Symptom | Probable Cause | Remedy |
|--|---|---|
| <i>PCEr</i> | Unit-Percentage -Weight is error, it's too small (the weight of 1%, 0.1%, or 0.01%-determined by CONFIG-FUNC-PERCNT is less than 0.5d). | Use more weight for the sample. |
| <i>StbEr</i> | USER-HOLD-STB.TIM is too short, USER-HOLD-HLD.RG is too small, other failure. | Set USER-HOLD-STB.TIM longer, or set USER-HOLD-HLD.RG bigger. Service required. |
| Will not turn on. | Power cord not plugged in or properly connected. Power outlet not supplying electricity. Battery discharged. Other failure. | Check power cord connections. Make sure power cord is plugged into the power outlet. Check power source. Replace batteries. Service required. |
| Cannot zero the display or will not zero when turned on. | Load on scale exceeds allowable limits. Load on scale is not stable. Load cell damage. | Remove load on scale. Wait for load to become stable. Service required. |
| Cannot display weight in desired weighing unit. | Unit not set to enable or $d \geq 5oz$, when unit is lb:oz. | Enable unit in CONFIG-UNITS. |



Brecknell USA

1000 Armstrong Dr.

Fairmont MN 56031

Tel:507-238-8702

Fax:507-238-8271

Email: sales@brecknellscales.com

<http://www.brecknellscales.com>

Brecknell UK

Foundry Lane,

Smethwick, West Midlands,

England B66 2LP

Tel:+44 (0) 8452 46 6717

Fax:+44 (0) 8452 46 6718

Email:

sales@brecknellscales.co.uk

<http://www.brecknellscales.com>