

PODIUM ASSEMBLY INSTRUCTIONS

1. Attach base plate (3) to main support column (1) using the 4 provided 1/4-20 x 1" flathead screws as shown.
2. Attach PC head (6) to head mount bracket (7) using 4x M4x8 screws
3. Attach the head to the main support column. Attach any peripherals and printer (5) or keyboard (4) trays (if applicable).
4. Route all of the cabling and power through main support column.
5. Attach back cover (2) using the 10 provided 8-32 x 3/8" screws as shown.

