
INSTALLATION INSTRUCTIONS



K1 Single Column with iPad®2/iPad®3 Mount



K1C1I2B

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



IMPORTANT SAFETY INSTRUCTIONS

WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.



CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.

WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all components located between the K1C1I2B up to (and including) the display does not exceed 25 lbs (11.34 kg).

WARNING: Use this mounting system only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.




WARNING: Never operate this mounting system if it is damaged. Return the mounting system to a service center for examination and repair.

WAR

WARNING: Do not use this product outdoors.

--SAVE THESE INSTRUCTIONS--


DIMENSIONS




LEGEND

	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
(Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
6	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Llave de cabeza hexagonal	Llave de seguridad
	Sechskantschlüssel	Sicherheitsschlüssel
	Chave de cabeça sextavada	Chave de segurança
	Chiave esagonale	Chiave di sicurezza
	Zeskantsleutel	Veiligheidssleutel
	Clé à tête hexagonale	Clé de sécurité

TOOLS REQUIRED FOR INSTALLATION



PARTS



Assembly And Installation

Connecting Arm Assembly to Desk Standard Installation

 Loosen clamp screw until enough space is created between clamp and mount to allow for desk mounting. (See Figure 1)

NOTE: If space is limited behind desk (i.e. against wall, etc.), remove clamp screw and attachment entirely and reattach clamp screw prior to Step 3! (See Figure 2)

- Place mount on top of desk at desired mounting location. (See Figure 1)
- 3. Tighten clamp using clamp screw until mount is securely fastened to desk. (See Figure 1)




Figure 1




Figure 2

Low Profile Installation

- 1. Remove top cap from column. (See Figure 3)
- 2. Slide mount assembly off of column. (See Figure 3)




Figure 3

- 3. Rotate mount 90 degrees in either direction prior to reinstalling onto column. (See Figure 4)
- Reinstall onto column and adjust to desired height. (See Figure 4)
- 5. Reinstall top cap to column. (See Figure 4)




Figure 4

iPad2®/iPad3® Installation

 Remove quick release faceplate from arm assembly (A) by pressing quick release tab and sliding faceplate off mount. (See Figure 5)




Figure 5

 Use four M4x12mm Phillips pan machine screws (D) to connect faceplate to adapter plate. (See Figure 6)




Figure 6

Reinstall faceplate to mount.

 Use four M4x12 Phillips flat head screws (C) to connect iPad® interface (E) to adapter plate (B). (See Figure 7)




Figure 7

IMPORTANT!: The K1C1I2B is designed specifically for use with the iPad®2 or iPad®3. Other portable tablet devices may not fit properly into the interface.

- Fit the iPad® into the interface (E), bottom edge first. (See Figure 8)
- Angle the iPad® back while pressing back on the locking tab of the mount. (See Figure 8)
- 7. Fit the top edge of the iPad® under the tab. (See Figure 8)




Figure 8

8. To release the iPad® from the mount, firmly hold the iPad® while pressing back on the tab to release and remove the iPad®. (See Figure 9)




Figure 9

- Position iPad® with faceplate attached above mount. (See Figure 10)
- 10. Slide faceplate onto mounting head until quick release tab clicks into place. (See Figure 10)




Figure 10

Adjustments

Column Height Adjustment

- 1. Loosen column adjustment knob. (See Figure 11)
- 2. Adjust height to desired level. (See Figure 11)
- 3. Tighten column adjustment knob. (See Figure 11)





Figure 11

Pivot Adjustment Range

injury!

 Adjust arm angle as desired up to 90 degrees in either direction. (See Figure 12)






Figure 12

Head Tilt Adjustment

- 1. Adjust head tilt to desired tilt position. (See Figure 13)
- Adjust head tilt tension screw to change the adjustment tension. (See Figure 13)

Height Adjustment

- Adjust height to desired level. (See Figure 13)
- Open cable management cover on upper arm to expose height-adjustable tension screw. See Cable Management section for details.
- 3. Use 1/8" hex key (K) to adjust height-adjustable tension screw to change adjustment tension. (See Figure 13)
- Close cable management cover on upper arm. See Cable Management section for details.

Pivot Adjustment

- 1. Adjust pivot position as desired. (See Figure 13)
- Use 3/16" hex key (J) to adjust pivot point tension screws to change pivot adjustment tension. (See Figure 13)




Figure 13

Portrait Adjustment

The iPad® may be adjusted 90 degrees in either direction in order to provide a portrait view of the iPad®.




Figure 14

Cable Management

 Route cables through cable management channel on upper arm. (See Figure 15)




Figure 15



Our Mounts. Your Vision.

Chief Manufacturing, a products division of Milestone AV Technologies

8800-002197 Rev00 ©2012 Milestone AV Technologies, a Duchossois Group Company www.chiefmfg.com 06/12 **USA/International**

Europe

A 6436 City West Parkway, Eden Prairie, MN 55344

P 800.582.6480 / 952.225.6000

F 877.894.6918 / 952.894.6918

A Franklinstraat 14, 6003 DK Weert, Netherlands

+31 (0) 495 580 852

F +31 (0) 495 580 845

Asia Pacific A Office No.

A Office No. 1 on 12/F, Shatin Galleria 18-24 Shan Mei Street

Fotan, Shatin, Hong Kong

P 852 2145 4099

F 852 2145 4477

