

Box Contents

1x E-Series Touchcomputer with Stand
1x 19V Power Brick
1x 1.8m US Power Cable
1x 1.8m EU Power Cable
2x Cable Tie



Quick Installation Guide

14-INCH E-SERIES FOR ANDROID

Learn more about Elo at [EloTouch.com](https://www.elotouch.com)

Revision A
P/N E266303

America

Tel +1 408 597 8000
EloSales.NA@elotouch.com

Asia-Pacific

Tel +86 (21) 3329 1385
EloAsia@elotouch.com

Europe(EMEA)

Tel +32 16 930 136
EMEA.Sales@elotouch.com

The information in this document is subject to change without notice. Elo Touch Solutions, Inc. and its Affiliates (collectively "Elo") makes no representations or warranties with respect to the contents herein, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo to notify any person of such revisions or changes.


No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo Touch Solutions, Inc.

Elo and the Elo logo are trademarks of Elo Touch Solutions, Inc., registered in many jurisdictions worldwide.




Go to www.elotouch.com/support to download user manual.


- 1 Loosen the locking screw, then unclip the cable cover from the display.




- 2 Connect the power adapter. Make additional connections as needed. Connect Edge Connect peripherals to edge Micro USB ports by removing covers as shown.



- 3 Route cables through guide fingers in display and stand, through hole in base of stand. Ensure adequate cable slack so that display can tilt freely.



- 4 Reinstall the cable cover by snapping into the display and tightening the screw from Step 1. Press Power Button.



- 5 The POS stand can be configured with optional 10" CFD or 10" CFD with NFC.



I-Series Head 14" + Stand with
10.1" CFD



I-Series Head 14" + Stand with
10.1" CFD with NFC



EU Battery Regulation

This symbol on the battery(ies) or on the packaging indicates that the battery(ies) provided with this product should not be treated as household waste. Instead, please separate the battery(ies) from other types of waste and recycle them through your local recycling system to protect the environment and health. The chemical symbol for lead (Pb) is added under this symbol if the battery(ies) contains more than 0.004% lead. Additionally, the chemical symbol for cadmium (Cd) is added under this symbol if the battery(ies) contains more than 0.002% cadmium.

For more detailed information about the recycling of these batteries, please contact your local authority or the shop where you purchased the product or batteries.