



## **UL90 Installation Instructions**




Locate the stud in the wall you are mounting to and mark the top hole. Drill 11/64 pilot hole and insert the provided #14 wood screw, tightening slightly. Using a level, mark the lower hole and drill pilot hole, insert the last #14 screw and, with the unit level, tighten both screws.


Note: #14 wood screws are supplied; if installing into metal studs you will need to use proper metal stud fasteners.

If your monitor is over 17", the mount may be more effective if mounted upside down.





Drill a 3/8 hole through the horizontal surface you intend to mount to and push the 3/8 stud on the desk mount through the hole. Slip the large mounting washer over the stud from underneath, add the 3/8 split-washer, and secure in place with the 3/8 nylock.





Using the 1/4" hex key, separate the two halves of your pole mount as shown, place around pole at the desired height and reassemble.





Thank you for your purchase of an ICW UL90 monitor mount. Any questions? Contact ICW at 1-800-558-4435.